
- RYOBI 4V BATTERY PACK - MODEL NO. AP4000 -

The model number will be found on a label attached to the housing. Always mention the model number in all correspondence regarding your **BATTERY PACK** or when ordering replacement parts.



KEY NO.	PART NUMBER	DESCRIPTION	QTY.	KEY NO.
1	130166001	Battery Pack	1	
2	940976569	Data/Warning Label	1	

KEY NO.	PART NUMBER	DESCRIPTION	QTY.
	NOT SHOWN:		
	987000652	Operator's Manual	1
	7-29-09 (REV:01)		