





Parts Breakdown

BMR100

Products with multiple versions are listed in subsiding order with the newest version on top not indented

<u>Fig #</u>	<u>Part ID</u>	<u>Part Name</u>	<u>Quantity</u>
1	SE00000010	CIRCUIT BOARD A ASSY, BMR100	1
1	SE00000036	CIRCUIT BOARD A ASS'Y, BMR100W	1
2	SE09163102	SCREW M3X10, BMR100	12
3	SE00000011	CIRCUIT BOARD C ASSY, BMR100	1
3	SE00000037	CIRCUIT BOARD C ASS'Y, BMR100W	1
4	SE024PC040	PACKING, BMR100	1
5	SE09090011	SCREW 1.7, BMR100	13
6	SE020PC020	POWER BUTTON HOLDER,BMR100	1
7	SE0310PC5Z	POWER BUTTON, BMR100	1
8	SE020PC030	PRESET BUTTON HOLDER,BMR100	1
9	SE0312PC5Z	PRESET BUTTON, BMR100	1
10	SE09064161	SCREW M4X16, BMR100	1
11	SE09163082	SCREW M3X8, BMR100	1
12	SE09064161	SCREW M4X16, BMR100	2
13	SE00000005	FRONT CABINET ASS'Y, BMR100	1
14	SE09163082	SCREW M3X8, BMR100	1
15	SE09064161	SCREW M4X16, BMR100	1
16	SE0331PC5Z	FRONT BUMPER, BMR100	1
17	SE0338PC5Z	FRONT BAR, BMR100	2
18	SE09176426	SCREW M6X42, BMR100	4
19	SE0313PC5Z	ROTARY KNOB, BMR100	1
20	SE21B1110A	ROTARY KNOB RING, BMR100	1
21	SE00000042	JACK COVER, BMR100W	1
21	SE0335PC5Z	JACK COVER, BMR100	1
22	SE09173106	HEX. SCREW M3X10, BMR100	1
23	SE0334PC5Z	BATTERY COVER BUMPER, BMR100	1
24	SE09176106	HEX. SCREW M6X10, BMR100	2
25	SE09176106	HEX. SCREW M6X10, BMR100	2
26	SE024J9070	PACKING, BMR100	2
27	SE0333PC5Z	REAR BUMPER, BMR100	1
28	SE0340PC5Z	ID LABEL, BMR100	1
29	SE0304PC5Z	BATTERY COVER, BMR100	1
30	SE021PC030	BATTERY COVER LOCKER, BMR100	1
31	SE9076146A	HEX. SCREW M6X14, BMR100	1
32	SE309PC5ZR	HANDLE COVER R, BMR100	1
33	SE0309J96A	HANDLE, BMR100	1
34	SE309PC5ZL	HANDLE HOLDER L, BMR100	1
35	SE9076146A	HEX. SCREW M6X14, BMR100	1
36	SE09176166	HEX. SCREW M6X16, BMR100	1
37	SE021J9090	SPRING, BMR100	2
38	SE09994007	STEEL BALL, BMR100	2
39	SE021J9070	HANDLE SUS-PLATE, BMR100	1
40	SE021J9070	HANDLE SUS-PLATE, BMR100	1
41	SE09994007	STEEL BALL, BMR100	2
42	SE021J9090	SPRING, BMR100	2
43	SE09176166	HEX. SCREW M6X16, BMR100	1
44	SE09163102	SCREW M3X10, BMR100	2
45	SE09163062	SCREW M3X6, BMR100	2
46	SE021PC000	BATTERY CUSHION, BMR100	1
47	SE024PC010	PACKING, BMR100	1
48	SE023PC030	SPACER, BMR100	1
49	SE0307PC5Z	B-UP BATTERY COVER, BMR100	1
50	SE021E9010	BATTERY CONTACT (+), BMR100	1
51	SE021E9020	BATTERY CONTACT (-), BMR100	1
52	SE021E9030	+/- BATTERY CONTACT ASSY, BMR100	1
53	SE09163452	SCREW M3X45, BMR100	2
54	SE0308PC5Z	BATTERY COVER LOCKER,BMR100	1
55	SE0314PC5Z	LOCKER HINGER, BMR100	1
56	SE021PC040	LOCKER FIXER PIN 79.5,BMR100	1
57	SE00000033	ROD ANT, BMR100W	1
57	SE0360PC5J	ROD ANT, BMR100	1
58	SE021J9032	ROD ANT HOLDER, BMR100	1
59	SE024J9050	PACKING, BMR100	1
60	SE021PC050	LOCKER FIXER PIN 63.8,BMR100	1



Parts Breakdown

BMR100

61	SE021PC100	ROD ANT TERMINAL, BMR100	1
62	SE021P0020	NUT, BMR100	1
63	SE024J9030	PACKING, BMR100	1
64	SE01620771	SPEAKER, BMR100	1
65	SE09090023	SCREW M4X12, BMR100	4
66	SE00000006	SPEAKER NET, BMR100	1
67	SE024J9090	PACKING, BMR100	4
68	SE024J9070	PACKING, BMR100	4
69	SE024J9040	PACKING, BMR100	4
70	SE9076146A	HEX. SCREW M6X14, BMR100	4
71	SE021J9010	SPEAKER HOLDER, BMR100	1
72	SE023PC020	EVA 25X18X5.5, BMR100	1
73	SE09163102	SCREW M3X10, BMR100	2
74	SE023PC000	SPACER, BMR100	1
75	643926-9	BATTERY HOLDER, ML180	1
75	GM00000530	BATTERY HOLDER,BML184	1
76	SE09153102	SCREW M3X10, BMR100	2
77	SE020PC050	SLIDE BATTERY HOLDER,BMR100	1
78	643926-9	BATTERY HOLDER, ML180	1
78	GM00000530	BATTERY HOLDER,BML184	1
79	SE09163102	SCREW M3X10, BMR100	2
80	SE020PC040	CLUSTER BATTERY HOLDER,BMR100	1
81	SE023PC020	EVA 25X18X5.5, BMR100	1
82	SE02311000	SPACER (A), BMR100	1
83	SE021J9010	SPEAKER HOLDER, BMR100	1
84	SE024J9030	PACKING, BMR100	1
85	SE09163452	SCREW M3X45, BMR100	2
86	SE00000041	N/A	1
86	SE0303PC5Z	BACK COVER, BMR100	1
87	SE01620771	SPEAKER, BMR100	1
88	SE09090023	SCREW M4X12, BMR100	4
89	SE00000006	SPEAKER NET, BMR100	1
90	SE024J9090	PACKING, BMR100	4
91	SE024J9070	PACKING, BMR100	4
92	SE024J9040	PACKING, BMR100	4
93	SE9076146A	HEX. SCREW M6X14, BMR100	4
1,001	SE00000002	AC ADAPTER, BMR100	1
1,001	SE00000015	AC ADAPTER, BMR100W	1