



## Parts List for BN200SB Type 1

Item Number	Part Number	Description	Qty Required
1	JA1191W1	FLANGE NUT	1
2	JA1162E1	EXHAUST COVER	1
3	1A105401	HEX SOC.HD.BOLT	4
4	1D105	SPRING WASHER	1
5	9R195628	FRAME CAP-MACHINING	1
6	MRG002514	O-RING-.098X.055	1
7	1L103061	BUTTON HD.CROSS SOC.	1
8	JA1151C1	PACKING	1
9	180447	SPRING	1
10	1FP0015	O-RING	1
11	180449	WASHER FLAT	1
12	180450-S	HEAD VALVE BODY	1
13	180448	O RING	1
16	JS1082U1	DRIVER UNIT	1
17	1FZ0009	O-RING	1
18	188708	CYLINDER	1
19	851483-S	O-RING	1
20	JA1111O1	BUMPER	1
21	JS1121I1	JOINT GUIDE	1
22	FA205BA1	TRIGGER VALVE UNIT	1
23	174073	O-RING	1
24	9R199839	TRIGGER ASSEMBLY	1
25	JA2071W1	STEPPED PIN	1
26	9R199844	FRAME, BN200SB	1
27	JA3612D1	END CAP	1
28	1FZ0019	O-RING	1
29	1A105201	HEX SOC.HD.BOLT	2

## Parts List for BN200SB Type 1

Item Number	Part Number	Description	Qty Required
30	JS4013M1	DRIVER GUIDE COVER A	1
31	JS4033H1	DRIVER GUIDE	1
32	1A104161	HEX SOC.HD.BOLT	2
33	188692	MAGAZINE- FIXED	1
34	189859	NAIL GUIDE	1
35	JS4091I1	PUSHER	1
36	JA4172E1	ROLLER	1
37	JA4141S1	SPRING	1
38	MPG030012	PIN SPRING	1
39	189858	MAGAZINE- SLIDING	1
40	JA4191S1	SPRING	1
41	9R199846	CLICK LEVER	1
42	JA4181W1	CLICK LEVER PIN	2
43	1L104103	BUTTOM HD.SOC.SCREW	4
44	JA4501I1	END COVER PLATE	2
45	JS4261E1	END COVER	1
46	JS4211I1	REAR PLATE	1
47	1D104	SPRING WASHER	1
48	1A104061	HEX SOC.HD.BOLT	1
49	MHE5080-100	NUT-NYLON M5X.80	1
50	180569	WASHER-PLAIN-D5X10X1	1
51	JA5073I1	SAFETY B	1
52	JS5082E1	SAFETY COVER	1
53	JA5131I1	SHOULDER SCREW	3
54	JA5161W1	SETTING KNOB	1
55	JA5092S1	SPRING	1
56	JS5062I1	SAFETY A	1

## Parts List for BN200SB Type 1

Item Number	Part Number	Description	Qty Required
57	180507	E-RING	1
58	9R199845	NO MAR TIP	1
59	JA5141E1	SAFETY GUIDE	1
60	9R198008	WARNING LABEL	1
61	188686	BRACKET MAGAZINE	1
62	MSC4070-8	SCREW-SHCS-M4X0.70X8	2
63	S112218410	AIR FITTING	1
64	9R198007	MODEL LABEL, BN200SB	1
65	9R195600	LABEL-WARNING	1
66	9R197976	LABEL, PC LOGO	1
800	100679	LUBE (1LB.CAN)	1
800	100653	LUBE (2CC)	1