



BOSCH

Stand

BT 170 HD | 3 601 K91 310

Table of Content


Spare parts list.....	2
Illustration - Type.....	3

Spare parts list

Item	Part Number	Description	Illustration
801	1 600 A00 092	Clamp Screw	1
804	1 600 A00 0A1	Rubber Base	1
805	1 600 A00 093	Clamping Unit	1
808	1 600 A00 0A3	Guide	1
810	1 600 A00 0A2	Stand Leg	1
811	2 610 A09 293	Carrying Strap	1
812	2 610 A09 381	Head	1
813	2 610 A09 402	Swing-Plate	1
814	2 610 A14 607	Clamp	1
815	2 610 A14 608	Swing Clamp	1
816	2 610 A14 609	Bolt	1
817	2 610 A09 286	Bushing	1
818	2 610 A09 014	Stand Foot	1

Illustration - Type - E

3 601 K91 200
 Issue | 05-08-14
 Stand | 10-09-15 **Fig./Abb. 1**



Änderungen vorbehalten
 Modifications reserved
 Modificaciones reservées
 Salvo modificaciones