

ELECTRIC TOOL PARTS LIST

■ CORDLESS CIRCULAR SAW
Model C 18DGL

2015 • 06 • 23
(E1)



