

Parts List for CS1216 Type 1

Item Number	Part Number	Description	Qty Required
1	5140162-29	CAP ASSEMBLY	1
2	5140162-34	SEALING RING	1
3	5140162-35	OIL BOX ASSY.	1
4	5140159-35	CORD	1
5	5140162-42	CORD PROTECTOR	1
6	5140159-37	TAPPING SCREW	3
7	5140159-38	CORD CLAMP	1
8	5140159-39	CONNECTOR	2
9	5140162-43	COPPER STRIP	1
10	5140162-44	LEADWIRE	1
11	5140162-45	LEADWIRE	1
12	5140159-42	SPRING	1
13	5140162-46	TRIGGER	1
14	5140162-47	SPRING	1
15	5140162-48	LOCK OFF BUTTON	1
16	5140159-46	TAPPING SCREW	1
17	5140158-95	MICRO SWITCH	1
18	5140162-49	LEADWIRE	1
19	5140159-48	HEX NUT	1
20	5140159-49	MOTOR PINION	1
21	5140159-50	BUSHING	1
22	5140162-50	SELF TAPPING SCREW	11
23	5140162-51	HOUSING	1
24	5140162-52	ARMATURE ASSEMBLY	1
25	5140162-56	WASHER	1
26	5140162-57	FIELD CASE ASSY	1
27	5140162-66	BRUSH	2

Parts List for CS1216 Type 1

Item Number	Part Number	Description	Qty Required
28	5140159-54	CLAMP	2
29	5140159-55	TAPPING SCREW	4
30	5140162-67	REAR COVER	1
31	5140162-68	SELF TAPPING SCREW	2
32	5140149-82	WASHER	1
33	5140162-69	KICKBACK,ANTI	1
34	5140162-70	OIL PUMP ASSY.	1
35	5140159-34	TUBE	1
36	5140159-67	CONNECTOR	1
37	5140159-68	RUBBER RING	2
38	5140162-74	OUTPUT SHAFT	1
39	5140162-79	DUST SHIELD	1
40	5140162-80	HOUSING	1
41	5140159-78	TENSION SPRING	1
42	5140159-23	SPROCKET	1
43	5140162-89	BAFFLE	1
44	5140159-80	LOCK WASHER	1
45	5140162-90	SELF TAPPING SCREW	11
46	5140162-91	SELF TAP SCREW	1
47	5140162-93	CHAIN	1
48	5140162-92	BAR	1
49	5140162-94	ADJUSTOR	1
50	5140162-98	SHEATH	1
131	5140162-36	VALVE	1
132	5140162-37	OIL TANK	1
133	5140162-38	PLUG	1
134	5140162-39	SPONGE	1

Parts List for CS1216 Type 1

Item Number	Part Number	Description	Qty Required
135	5140162-40	CONNECTOR	1
136	5140162-41	SLEEVE	1
137	5140159-34	TUBE	1
241	5140162-53	BEARING	1
243	5140162-55	BEARING	1
261	5140162-58	SCREW	2
262	5140162-59	SPRING WASHER	2
263	5140162-60	GASKET	2
264	5140162-61	BAFFLE	1
265	5140162-62	FIELD	1
266	5140162-63	FIELD CASE	1
267	5140159-52	BRUSH HOLDER	2
268	5140162-64	WASHER	2
269	5140162-65	HEX NUT	2
341	5140162-71	WORM GEAR	1
342	5140162-72	WORM GEAR	1
343	5140162-73	MAIN PUMP	1
344	5140159-62	FLANGE BOLT	1
381	5140149-43	SELF TAPPING SCREW	1
401	5140162-81	PLUG	1
402	5140159-37	TAPPING SCREW	2
403	5140162-82	CLAMP	1
404	5140162-83	STUD	1
406	5140162-85	LEVER ASSEMBLY	1
407	5140162-86	ADJUSTING KNOB	1
408	5140162-87	PAWL	1
409	5140159-72	COUNTERSUNK SCREW	2

Parts List for CS1216 Type 1

Item Number	Part Number	Description	Qty Required
410	5140162-88	SEAL	1
494	5140159-25	OIL SEAL	1