




Product Description: Chain Saw  
Model Number: CS4562B-00  
Body Number: 0640015002  
Version: A  
Issue Date: 2021/05/12



No.	Product Model#	Part Number	Description	Qty
1	CS4562B-00	3131494001	Sheath	1
2	CS4562B-00	3131400001	Front Handle	1
3	CS4562B-00	3131466001	Lock off Button	1
4	CS4562B-00	3660427001	Spring	2
5	CS4562B-00	3131565001	Brake Handle	1
6	CS4562B-00	3130337001	Rubber Gasket	1
7	CS4562B-00	2827672002	Cover Assembly	1
8	CS4562B-00	5620479001	Screw	17
9	CS4562B-00	2823836001	Kettle Assembly	1
10	CS4562B-00	2827795002	Pump Assembly	1
11	CS4562B-00	5610022001	Tapping Screw	2
12	CS4562B-00	3131467001	Switch Trigger	1
13	CS4562B-00	3131437001	Fan Baffle	1
14	CS4562B-00	3130974001	Base	1
15	CS4562B-00	2827815001	Driving Wheel Assembly	1
16	CS4562B-00	2827223001	Kettle Cover Assembly	1