


REPLACEMENT PARTS

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
* 1	1343185	Guard Assembly, Const. of:	53	36-516	Table Insert, Incl:
2	1343186	Guard	54	1343216	#10 x 3/8" Pan Hd Sheet Met Screw
3	901-01-060-3124	1/4-20 x 1 1/2" Hex Hd Screw	55	1343217	Speed Nut
4	904-03-013-1492	1/4" Ext Tooth Lockwasher	56	1343219	Table, Incl:
5	902-01-120-1034	1/4-20 Hex Nut	56A	1343266	Scale
6	1343261	Rubber Bumper	57	1343218	1/4-20 x 1" Flat Hd Screw
7	1343189	Support	58	1343220	1/4-20 x 1 1/2" Fil Hd Tap Screw
8	1343187	Rivet	59	1343221	Base
9	1343188	Clip	60	1246140	(DIN 125) M6 Flat Washer
10	1343193	Anti-Kickback Finger	61	1310157	(DIN 85) M6 x 20mm Cheese Hd Screw
11	1343194	Spacer	62	1343222	Base Plate
12	1343196	Spring	63	1343237	Gear Plate
13	1310311	(DIN 1481) Ø4 x 22mm Roll Pin	64	1330398	(DIN 963) M4 x 12mm Flat Hd Screw
14	1343190	Spacer	65	1343224	Nameplate
15	1343195	Splitter	66	1343223	(DIN 963) M3 x 6mm Flat Hd Screw
16	902-01-120-1034	Pin	67	904-07-010-5555	1/4" Fiber Washer
17	901-01-060-5768	1/4-20 Hex Nut	68	1343225	Tilt Lock Lever
18	904-03-020-1764	1/4-20 x 2 1/4" Hex Hd Screw	69	902-01-120-1034	1/4-20 Hex Nut
19	904-01-010-1603	1/4" Int Tooth Lockwasher	70	1343227	Handle
20	1343191	1/4" Flat Washer	71	1343228	1/4-20 x 1 1/2" Flat Hd Screw
21	904-03-013-1492	Splitter Bracket	72	1343226	Handwheel
22	1343264	1/4" Ext Tooth Lockwasher	73	1343229	Screw Rod
23	904-03-013-1492	Splitter Support Bracket	74	1310311	(DIN 1481) Ø4 x 22mm Roll Pin
24	901-01-060-0611	1/4" Ext Tooth Lockwasher	75	438-01-017-0140	Switch, Incl:
* 25	1343197	1/4-20 x 1/2" Hex Hd Screw	76	400-06-068-0002	Switch Key
26	1343198	Miter Gage Assembly, Const of:	77	1343231	Sleeve
27	904-01-010-1603	Knob	78	1343232	Cord Clamp
28	1343199	1/4" Flat Washer	79	1343230	#10 x 3/4" Pan Hd Sht Metal Screw
29	902-01-120-1203	Fiber Washer	80	1343233	Breaker Switch w/Plate, Incl:
30	901-02-010-0541	Miter Gage Body	81	1313228	Milled Nut
31	1343200	#10-24 Hex Nut	82	1313234	Hex Nut
32	1343205	#10-24 x 3/4" Rd Hd Screw	83	1343230	#10 x 3/4" Pan Hd Sht Metal Screw
33	901-03-030-8013	Stud	84	1343235	Rubber Foot
34	1343204	Guide Bar	85	1343234	Switch Cover
35	901-02-140-3712	1/4-20 x 3/4" Flat Hd Screw	86	1246117	(DIN 963) M4 x 10mm Flat Hd Screw
36	904-01-010-1610	#10-24 x 3/8" Flat Hd Screw	87	1310210	(DIN 6797A) M4 Ext Tooth Lockwasher
37	1343201	#10-24 x 3/8" Pan Hd Screw	88	1313235	Power Cord
38	1343202	Pointer	89	1340654	(DIN 125) M4 Flat Washer
39	1343203	Guide Block	90	1243569	(DIN 934) M4 Hex Nut
* 40	1343214	Pin	91	1343236	Wrench
41	1343206	Rip Fence Assembly, Const of:	92	1313197	15/16" Arbor Wrench
42	1343207	Lock Rod	*		NOT SHOWN ASSEMBLED
43	1343208	Rear Clamp			
44	1343209	Spring			
45	1343210	Block			
46	901-01-060-0611	Fence Body			
47	904-03-013-1492	1/4-20 x 1/2" Hex Hd Screw			
48	901-02-140-3712	1/4" Ext Tooth Lockwasher			
49	1343215	#10-24 x 3/8" Bind Hd Screw			
50	1343211	Pointer			
51	1343212	Front Block			
52	904-01-010-1603	Front Clamp			
		1/4" Flat Washer			
		Knob			



REPLACEMENT PARTS

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
* 100	1343257	Motor Assembly, Const of:	141	1343241	Mounting Plate
101	438-01-004-0062	Strain Relief	142	1343251	(DIN 1481) Ø8 x 3 1/2" Roll Pin
102	1343273	Motor Cord w/Terminals	143	902-08-041-3065	1/4-20 Special Nut
103	438-01-007-0042	Wire Nut	144	1320165	E5 Retaining Ring
104	1341235	(DIN 84) M4 x 12mm Cheese Hd Screw	145	1343243	Bracket
105	1343271	Pad	146	904-01-031-2934	1/4" Flat Washer
106	1343272	End Cap	147	1343249	Block
107	1343270	Brush Housing	148	1343250	Spacer
108	1343269	Brush	149	902-01-020-5433	3/8-16 Thin Hex Nut
109	1243595	(DIN 934) M5 Hex Nut	150	904-01-031-2933	Fiber Washer
110	1310146	(DIN 85) M5 x 30mm Pan Hd Screw	151	904-01-031-7706	3/8" Flat Washer
111	1340359	(DIN 6798A) M5 Ext Tooth Lockwasher	152	1343275	(DIN 137A) 10mm Wave Washer
112	1343268	Motor Housing	153	902-01-120-1216	#10-24 Hex Nut
113	1343267	Wavy Washer	154	901-11-020-0819	1/4-20 x 1 1/4" Carriage Bolt
114	400-08-139-0006	Commutator Bearing	155	1343242	Spacer
115	1343263	Field	156	904-01-010-1603	1/4" Flat Washer
116	1340359	(DIN 6798A) M5 Ext Tooth Lockwasher	157	902-01-120-1034	1/4-20 Hex Nut
117	1343265	(DIN 931) M5 x 60mm Hex Hd Screw	158	1343225	Tilt Lock Lever
118	1343262	Armature	159	901-01-060-9596	1/4-20 x 3 1/4" Hex Hd Screw
119	400-08-139-0008	Fan End Bearing	160	1343244	Plate
120	1343260	Gear Housing	161	904-03-030-1760	#10 Ext Tooth Lockwasher
121	1343259	Needle Bearing	162	901-02-140-3712	#10-24 x 3/8" Bind Hd Screw
122	1343258	Jackshaft Assembly	163	904-01-031-7706	3/8" Flat Washer
123	1243525	(DIN 7980) M4 Lockwasher	164	1343245	Spring
124	1341235	(DIN 84) M4 x 12mm Cheese Hd Screw	165	904-01-010-6076	1/2" Flat Washer
125	422-04-103-5009	10" Blade	166	1343246	Spring
126	1343256	Flange	167	1343226	Handwheel
127	1343255	Arbor Nut	168	901-01-060-0629	5/16-18 x 5/8" Hex Hd Screw
128	902-08-041-3065	Bracket	169	904-03-050-1752	5/16" Int Tooth Lockwasher
129	1343254	1/4-20 Special Nut	170	1343247	Pointer Bracket
130	901-01-060-9596	Spacer	171	902-01-040-1030	5/16-18 Hex Nut
131	1246014	1/4-20 x 3 1/4" Hex Hd Screw	172	1343248	Pointer
132	901-06-163-1484	(DIN 933) M6 x 15mm Hex Hd Screw	173	904-03-030-1760	#10 Ext Tooth Lockwasher
133	904-03-030-1795	#10-24 x 3/4" Hex Hd Screw	174	901-02-140-3712	#10-24 x 3/8" Bind Hd Screw
134	901-01-060-0626	#10 Ext Tooth Lockwasher			
135	1343252	1/4-20 x 3/4" Hex Hd Screw			
136	1343253	Pivot Bracket			
137	1343239	Saddle			
138	1343238	Pivot Rod			
139	1343240	Strap			
140	902-08-041-3065	1/4-20 Special Nut			

* NOT SHOWN ASSEMBLED

This parts list is provided to aid in obtaining service parts. Operational and maintenance information is contained in a separate owner's manual which is available through your local service outlet.