

PARTS LIST / MAINTENANCE

COBRA+TOOL PARTS LIST

| KEY | PART NO. | DESCRIPTION |
|-----|-----------|-------------------------------|
| 1 | SC490737 | SPALL GUARD |
| 2 | SC395332 | PLASTIC SLEEVE |
| 3 | SC250502 | PLASTIC BUFFER |
| 4 | SC395330 | FASTENER GUIDE ASSEMBLY |
| 5 | SC395320 | PISTON ASSEMBLY |
| 6 | SC301208 | PISTON RING |
| 7 | SC302012 | PAWL (STOP) |
| 8 | SC395301 | BARREL |
| 9 | SC301014A | BARREL RETENTION ASSEMBLY |
| 10 | SC301016 | PUSH PIN |
| 11 | SC301046A | DETENT BALL ASSEMBLY |
| 12 | SC301034A | TRIGGER ASSEMBLY AND PIN |
| 13 | SC385001 | TOOL BODY |
| 14 | SC301113 | BOLT (2) |
| 15 | SC301300A | SEAR HOLDER ASSEMBLY |
| 16 | SC301531 | SPRING, ADVANCE BAR |
| 17 | SC301400 | FIRING PIN ASSEMBLY |
| 18 | SC301026A | FIRING PIN SPRING ASSEMBLY |
| 19 | SC301600 | HANDLE ASSEMBLY |
| 20 | SC355600 | POWER ADJUST ASSEMBLY |
| 21 | SC355610 | ADJUST PIN AND WHEEL ASSEMBLY |
| 22 | SC355601 | PANEL |
| 23 | SC355602 | PIN, PANEL |
| 24 | SC355603 | SPRING, PANEL |
| 25 | SC355604 | SCREW, LONG |
| 26 | SC355605 | SCREW, SHORT |

MAINTENANCE

IMPROPERLY MAINTAINED TOOLS CAN CAUSE SERIOUS INJURIES TO TOOL OPERATORS AND BYSTANDERS, CLEAN TOOL DAILY

Always make sure tool is not loaded before performing any service or repair and always wear safety goggles when cleaning or servicing the tool.

NORMAL CLEANING

All front end parts shown in the disassembly section are to be cleaned daily with a good detergent oil and wire brush. Remove all dirt and carbon buildup and wipe parts dry with a clean rag. Check all parts for wear or damage before reassembly and replace or repair any worn or damaged parts.

COMPLETE CLEANING / GENERAL MAINTENANCE

Heavy or constant exposure to dirt and debris may require that the tool be cleaned more extensively. Complete disassembly and cleaning of all parts may be necessary to restore the tool to normal operation. General maintenance should be performed every six months or more often if the tool is subjected to heavy use. Call 1-877-ITW-BRANDS (1-877-489-2726) for technical assistance.

ALWAYS FUNCTION TEST THE TOOL AFTER PERFORMING ANY SERVICE. SEE PAGE 9 FOR DETAILS ON THE FUNCTION TEST.