



ORDER BY FAX OR EMAIL

f: 800-529-8680 e: spcustomer.service@itwserviceparts.com

KEY	PART NO.	DESCRIPTION
1	323300	MUZZLE BUSHING ASSEMBLY
2	316520	BUFFER (PKG. OF 3)
3	30645	PISTON
4	323020MA	BARREL RETENTION COLLAR ASSY.
5	316540	PAWL (PKG. OF 2)
6	323390A	BARREL ASSEMBLY
8	308490	LATCH BUTTON ASSEMBLY
9	13510	COVER ASSEMBLY
10	307890	FIRING PIN ASSEMBLY
11	13513	FIRING PIN SPRING
12	335175M	RETURN SPRING
13	323050A	RETENTION CLIP & BEARINGS
14	316570	FIRING PIN PAWL & SPRING
15	13518	INDEXING LEVER & SPRING
16	13516	TRIGGER LOCK ASSEMBLY
17	316580	SEAR ASSEMBLY & PIN
18	309280	REAR HANDLE ASSEMBLY
19	308860	REAR HANDLE SCREWS & NUTS
20	13509	TRIGGER & PIN
21	12266	SPALL GUARD NOT SHOWN
22	351000	MUZZLE BUSHING O RING
23	351001	RETENTION SLEEVE O RING
25	323110	MUZZLE BUSHING SHROUD
26	32330038M	3/8 MUZZLE BUSHING ASSY. (NOT SHOWN)
—	309020	DANGER LABEL, BLACK

The Receiver Assembly is not available as a spare part.

ORDER BY FAX OR EMAIL

f: 800-529-8680 e: spcustomer.service@itwserviceparts.com