

# DUO-FAST

NAILERS STAPLERS FASTENERS

## Angle Finish Nailer

### DAFN-6480


0363697

DUO-FAST CORPORATION  
AN ITW COMPANY  
2400 GALVIN DRIVE  
ELGIN, ILLINOIS 60123-7883  
U.S.A.

06/01

© 2001 DUO-FAST Corporation

DAFN-186-6480



TORQUE IN - LBS  
±5 IN - LBS

Always Wear Safety Glasses

When Using Power Tools  
XA-1011 CLEAR  
XA-1022 TINTED

▲ DENOTES CHANGE

TOOLS MUST BE REPAIRED ONLY WITH FACTORY AUTHORIZED PARTS  
SIEMPRE REPAIRE LAS HERRAMIENTAS SOLAMENTE CON PARTES DE REPUESTO AUTORIZADAS POR DUO-FAST

**DAFN-6480**

KEY NO.	UNIQUE NO.	PART NO.	DESCRIPTION	REPLACES	KEY NO.	UNIQUE NO.	PART NO.	DESCRIPTION	REPLACES
1	0374538	TST-0101105A	HEX SOC HD BOLT	_____	39	1012781	TST-0401053A	SPRING PIN	_____
2	0374546	TST-AD0000AA	WASHER	_____	40	0387316	TST-AB1230BA	GUIDE, SAFETY LEVER	_____
3	1012750	TST-0301P06A	O-RING	_____	41	0387407	TST-AA0860BA	GASKET	_____
4	0374595	TST-AD0010AA	DEFLECTOR	_____	42	1012749	TST-AC0870BA	BOTTOM PLATE	_____
5	0374637	TST-0101153B	HEX SOC HD BOLT	_____	43	1012785	TST-0101152B	HEX SOC HD BOLT	_____
6A	0374702	TST-AM002A01	CAP ASSEMBLY	_____	44	0387605	TST-AC1090AA	NOSE	_____
7	0374769	TST-AA0030BA	GASKET	_____	45	0387795	TST-AB1080AA	DOOR	_____
8	0375972	TST-AM0040AA	PISTON STOPPER	_____	46	0388231	TST-0401102A	SPRING PIN	_____
9	0376152	TST-AB0060AA	SPRING	_____	47	0388249	TST-0401101A	SPRING PIN	_____
10	0376178	TST-0302S40A	O-RING	_____	48A	0388256	TST-AB111A01	LATCH ASSY	_____
11	0376335	TST-0302S50A	O-RING	_____	49	0388462	TST-AB1180AA	SPRING, SAFETY	_____
12A	0376392	TST-AM005A01	PISTON HEAD VALVE ASSY	_____	50A	0389254	TST-AB117A01	UPPER SAFETY LEVER ASSY	_____
13	0376467	TST-AA0240BA	RETAINING RING	_____	51	0539759	TST-AM1300AA	SAFETY GUIDE	_____
14	0376624	TST-0303001A	O-RING	_____	52	0539775	TST-AM1290AA	ADJUSTING NUT	_____
15	0377473	TST-0303002A	O-RING	_____	53	0539767	TST-AM1320AA	ADJUSTING SPRING	_____
16	0378281	TST-AA0250AA	CYLINDER SPACER	_____	54	0389270	TST-AN1200AA	LOWER SAFETY LEVER	_____
17	0378299	TST-0301P35A	O-RING	_____	55	0389320	TST-AM1270AA	RUBBER PAD	_____
18A	0378810	TST-AB028A01	DRIVER ASSY	_____	56	1012797	TST-0101101A	HEX SOC HD BOLT	_____
19	0378828	TST-AB0230AA	CYLINDER	_____	57A	1012747	TST-AC168A01	MAGAZINE ASSEMBLY	_____
20	0379743	TST-AA0260AA	CYLINDER RING	_____	58A	1012748	TST-AB170A01	BUSHING ASSEMBLY	_____
21	0380006	TST-AA0290AA	BUMPER	_____	59A	0390914	TST-AB171A01	SPIRAL SPRING ASSY	_____
22	0380378	TST-AB0300BA	DRIVER GUIDE	_____	60	1012746	TST-AC1750BA	PUSHER	_____
23A	1013037	TST-AA046A05	HANDLE ASSY	_____	61	0390948	TST-AB1760AA	SPRING, FEED PAWL	_____
24	0381129	TST-AA0470BA	GASKET	_____	62	0390955	TST-AB1770AA	PUSHER GUIDE	_____
25	1012812	> TST-AA0480C1	END CAP	<u>TST-AA0480BB</u>	63	0390922	TST-AB1740AA	ROLLER SHAFT	_____
26	0381814	TST-0101102B	HEX SOC HD BOLT	_____	64	0390963	TST-0104053A	HEX SOC HD BOLT	_____
27	0382051	TST-0302S125	O-RING	_____	65	0390989	TST-AB1780AA	STOPPER	_____
28	0382697	TST-0302S18A	O-RING	_____	66	0391557	TST-0201101A	LOCKNUT	_____
29	0382788	TST-AA0650AA	VALVE	_____	67	0390971	TST-0104051A	HEX SOC HD BOLT	_____
30	0384305	TST-0302S08A	O-RING	_____	68	0389726	TST-AB1800AA	MAGAZINE CAP	_____
31	0385500	TST-0302S10A	O-RING	_____	69	0392308	TST-0201151A	LOCKNUT	_____
32	1013038	TST-AM0660AA	VALVE PLUNGER	_____	70	0393728	TST-AC1790AA	BRACKET	_____
33	0386474	TST-0302S03A	O-RING	_____	71	0392902	TST-0501152A	FLAT WASHER	_____
34	1012815	TST-AB0710AB	SPRING	_____	72	0391649	TST-0101152A	HEX SOC HD BOLT	_____
35	1012979	TST-AR0670AA	PLUNGER	_____	73	0337444	XH-108-75	WARNING LABEL	_____
36	0386748	TST-0301P20A	O-RING	_____	74	0351247	XH-108-78	WARNING LABEL	_____
37	0386755	TST-AA0680AA	PLUNGER CAP	_____	76	0351254	XH-108-79	MODEL LABEL	_____
38A	1013039	TST-AA070A02	TRIGGER ASSY	_____	77	0353730	XH-108-30	ACTION LABEL	_____

\* = PART CHANGE / > = NEW PART