



Model DCF300Z Parts list

A = Standard Equipment

O = Circuit Diagram

Item#	Part#	Description	Q'ty	Unit
001	TE00000046	LOGO FRONT PLATE	1	PC.
002	TE00000101	PHILLIPS HEAD SCREW M4X10	4	PC.
003	TE00000047	FRONT GUARD	1	PC.
004	TE00000048	O-RING 32	2	PC.
005	TE00000049	FRONT FRAME	1	PC.
006	TE00000092	NUT M4	4	PC.
007	TE00000050	LOGO REAR PLATE	1	PC.
008	TE00000104	SCREW B 3X10	3	PC.
009	TE00000051	FAN BLADE LOCK	1	PC.
010	TE00000052	FAN BLADE	1	PC.
011	TE00000053	FRONT ARM	1	PC.
012	TE00000054	REAR ARM R	1	PC.
013	TE00000103	SCREW A 3X14	4	PC.
014	TE00000055	LEAF SPRING	1	PC.
015	TE00000101	PHILLIPS HEAD SCREW M4X10	2	PC.
016	TE00000103	SCREW A 3X14	4	PC.
017	TE00000056	MOTOR FRONT COVER	1	PC.
018	TE00000159	MOTOR	1	
019	TE00000058	REAR GUARD	1	PC.
020	TE00000059	REAR FRAME	1	PC.
021	TE00000103	SCREW A 3X14	6	PC.
022	TE00000060	MOTOR REAR COVER	1	PC.
023	TE00000104	SCREW B 3X10	2	PC.
024	TE00000100	REAR ARM L	1	PC.
025	TE00000103	SCREW A 3X14	4	PC.
026	TE00000069	LOCKNUT M10	1	PC.
027	TE00000061	WIRE PROTECTOR	1	PC.
028	TE00000062	COUPLING	1	PC.
029	TE00000103	SCREW A 3X14	4	PC.
030	TE00000063	STEEL BALL 6	3	PC.
031	TE00000064	COMPRESSION SPRING-5	3	PC.
032	TE00000065	SPINDLE	1	PC.
033	TE00000090	POM FLAT WASHER 16	1	PC.
034	TE00000089	POM PLATE	4	PC.
035	TE00000066	UPPER BASE	1	PC.
036	TE00000104	SCREW B 3X10	4	PC.
037	TE00000088	SEAT	1	PC.
038	TE00000154	SWITCH PCB BOARD	1	PC.
039	TE00000067	SWITCH PANEL	1	PC.
040	TE00000093	LABEL	1	PC.
041	TE00000086	PCB	1	PC.
042	TE00000103	SCREW A 3X14	2	PC.
043	TE00000068	FLANGE	1	PC.
044	TE00000091	FLAT WASHER 10	1	PC.
045	TE00000069	LOCKNUT M10	1	PC.
046	TE00000102	PHILLIPS HEAD SCREW M3X14	1	PC.
047	TE00000105	SCREW C 3X14	2	PC.
048	TE00000103	SCREW A 3X14	2	PC.
049	TE00000070	ADAPTOR PLATE	1	PC.
050	TE00000071	RUBBER CAP	1	PC.

051	TE00000104	SCREW B 3X10	1 PC.
052	TE00000087	FLAT WASHER 3	1 PC.
053	TE00000104	SCREW B 3X10	1 PC.
054	TE00000087	FLAT WASHER 3	1 PC.
055	TE00000072	LINK A	1 PC.
056	TE00000073	LINK B	1 PC.
057	TE00000155	SUB MOTOR	1
058	TE00000075	TERMINAL HOLDER	1 PC.
059	TE00000076	TERMINAL +WIRE	1 PC.
060	TE00000077	LOWER BASE	1 PC.
061	TE00000103	SCREW A 3X14	9 PC.
062	TE00000079	FRONT JOINT L	1 PC.
063	TE00000084	FOOT B	1 PC.
064	TE00000078	FRONT JOINT R	1 PC.
065	TE00000084	FOOT B	1 PC.
066	TE00000097	RUBBER SEAL	8 PC.
067	TE00000094	SIDE STEEL PIPE	1 PC.
068	TE00000095	STEEL PIPE R	1 PC.
069	TE00000082	REAR JOINT	1 PC.
070	TE00000083	FOOT A	1 PC.
071	TE00000080	PIPE HOLDER	2 PC.
072	TE00000081	REAR STEEL PIPE	1 PC.
073	TE00000103	SCREW A 3X14	16 PC.
074	TE00000096	STEEL PIPE L	1 PC.
075	TE00000094	SIDE STEEL PIPE	1 PC.
076	TE00000082	REAR JOINT	1 PC.
077	TE00000083	FOOT A	1 PC.
A01	TE00000110	ADAPTER	1