



Parts List for DCF899HB Type 3

Item Number	Part Number	Description	Qty Required
1	N392223	HOUSING ASSEMBLY	1
2	N186764	RUBBER PLUG	4
3	N426401	MOTOR & SWITCH ASSY.	1
5	N410641	SEAL-GEARBOX	1
6	N194994	ROLLER PIN	3
7	N389396	PLANET GEAR	3
8	N114027	THRUST WASHER	1
9	N415871	MECHANISM ASSY	1
11	N137055	FWD/REV BUTTON	1
12	N231799	LED ASSY	1
14	N392855	DETENT SPRING	1
15	N393603	SPEED SELECTOR	1
16	N394333	LENS	1
17	N071836	ROLL PIN	1
18	330019-04	SCREW,PLASTITE	9
19	N415875	ANVIL ASSY	1
20	N415872	NOSE CONE ASSY.	1
21	330019-16	SCREW	4
22	N238000	IDENT LABEL	1
23	N408083	SPEED LABEL	1
24	N404526	LABEL	1
25	N472529	RATING LABEL	1
26	N419514	DETENT PLATE	1
27	N403227	DETENT PIN	1
30	050056-00	O RING	1
31	086947-00	SPRING RING	1
41	N363283	GEARCASE	1

Parts List for DCF899HB Type 3

Item Number	Part Number	Description	Qty Required
42	N158641	BEARING	1
43	N389398	RING GEAR	1
44	N389400	RETAINING RING	1
45	N411414	O-RING	1
800	N017298	GREASE	1
862	N037466	TOOL BAG	1
866	DCB205	BATTERY PACK	1
871	DCB115	CHARGER	1