



Parts List for DCS350D1 Type 1

Item Number	Part Number	Description	Qty Required
1	N420220	HOUSING ASSEMBLY	1
3	N441236	WISE JAW	1
4	N441241	CAM	1
5	N433562	BOLT	1
6	N441237	GEARCASE	1
7	N420221	LED LIGHT	1
8	N453041	SPRING	1
10	N441238	GEAR	1
11	N400513	KEY	1
12	861349-00	CIRCLIP	1
13	N441239	PLATE	1
14	330045-69	THREAD FORMING SCREW	6
15	860079-02	CIRCLIP	1
16	N427318	GEAR ASSEMBLY	1
17	N427320	MOTOR ASSEMBLY	1
18	N390059	MOTOR MOUNT	1
19	N441240	GEAR ASSEMBLY	1
20	N427319	GEAR ASSEMBLY	1
21	N420218	SWITCH & MODULE	1
22	N400521	FWD/REV BUTTON	1
23	N411702	SPRING	1
24	N454243	COVER	1
26	098000-11	WRENCH	1
27	330019-37	SCREW	9
28	330019-12	SCREW	15
29	N416333	IDENT LABEL	1
31	N416334	RATING LABEL	1

Parts List for DCS350D1 Type 1

Item Number	Part Number	Description	Qty Required
32	N447901	SPRING WASHER	1
33	330019-01	SCREW PLASTITE	1
34	N453340	SCREW,PAN HD.	1
35	911281	SCREW	2
39	N437589	LABEL	1
40	N473495	DIE KIT	1
42	N268241	BELT HOOK KIT	1
856	DCS35038	DIE KIT	1
856	DCS35012	DIE KIT	1
862	N381993	TOOL BAG	1
866	DCB203	BATTERY PACK	1
871	DCB115	CHARGER	1