

Parts List for DCS367B Type 1

Item Number	Part Number	Description	Qty Required
1	N519011	MOTOR & SWITCH ASSY.	1
2	N071836	ROLL PIN	1
3	N454084	LOCK-OFF BUTTON	1
5	N453948	SPRING	1
6	N226256	SHOE ASSEMBLY	1
9	N143636	FELT SEAL	1
10	N435110	GEARCASE ASSY	1
11	N129171	ORING	1
12	N130874	SCREW #8X1.00 PAN HD	3
13	N143177	SPACER RING	1
14	N124072	THRUST RING	1
15	N115646	THRUST BEARING	1
16	N115647	THRUST RING	1
17	N406599	BEVEL GEAR ASSY	1
18	N115642	PLATE, THRUST	1
19	142940-00	SCREW	4
20	N195829	GEAR CASE COVER ASSY	1
21	621979-00	WEAR STRIP	2
22	618733-00	SHAFT SEAL	1
23	618477-00	FELT SEAL	1
24	N020720	SEAL PLATE	1
25	330045-43	SCREW,TAPTITE	1
26	N026647	SHAFT SERVICE KIT	1
27	000903-00	BALL	1
28	N252639	SLIDER	1
29	N426742	SPRING	1
30	658115-00	YOKE CHANNEL	1

Parts List for DCS367B Type 1

Item Number	Part Number	Description	Qty Required
31	617000-00	SADDLE	1
32	N191614	FLAT HD SCREW	2
33	N191590	LOCK NUT	2
34	N021857	BEARING	1
35	N115641	GASKET,GEARCASE	1
37	N131037	CAP	2
38	144457-02	SCREW	4
39	N412063	LEVER ASSEMBLY	1
40	N348279	LED ASSY	1
41	N519013	HOUSING ASSEMBLY	1
42	N467560	PLATE	1
45	949638-02	PLUG,RUBBER	2
50	330019-02	SCREW,PLASTITE	11
68	N473173	RATING LABEL	1
862	N454407	TOOL BAG	1
866	DCB205	BATTERY PACK	1
871	DCB115	CHARGER	1