



Parts List for DCS7485B Type 1

Item Number	Part Number	Description	Qty Required
1	N436623	GUARD ASSEMBLY	1
2	5140136-20	FENCE ASSEMBLY	1
3	N433484	THROAT PLATE	1
4	A24507	PUSH STICK	1
5	N435108	MITER GAUGE ASSY	1
6	5140179-59	FRONT RAIL	1
7	5140134-67	SCREW W/WASHER	8
8	5140179-60	INNER RAIL	2
9	N433468	TABLE	1
10	5140179-61	REAR RAIL	1
11	5140134-66	SCREW W/WASHER	2
12	5140032-07	POINTER	1
13	5140135-36	FLAT WASHER	4
14	5140135-37	COMPRESSION SPRING	2
15	5140179-62	LOCK SHAFT	1
16	5140032-15	FLAT WASHER	2
17	5140134-75	COMPRESSION SPRING	1
18	5140032-26	PIVOT BRACKET	1
19	5140134-83	SCREW AND WASHER	4
21	A26148	ANTI-KICKBACK	1
22	N435472	ANTI-KICKBACK	1
23	5140135-17	CAP SCREW	2
24	N437875	RIVING KNIFE	1
26	N477018	ARM	1
27	5140179-63	SCREW & WASHER	4
28	5140134-90	SCREW AND WASHER	1
30	5140135-60	SCREW AND WASHER	3

Parts List for DCS7485B Type 1

Item Number	Part Number	Description	Qty Required
31	N434667	ELEVATING SHAFT	1
32	N434666	ELEVATING SHAFT	1
33	5140135-25	FRONT TRUNNION	1
34	5140135-29	SCREW AND WASHER	4
35	5140135-31	SCREW AND WASHER	4
36	5140135-30	PIVOT BRACKET	1
37	5140135-61	LOCK NUT	1
38	5140117-77	HAND WHEEL	1
39	N434678	SHAFT	1
40	5140179-65	SPRING PIN	1
41	5140128-61	O-RING	1
42	5140032-50	KEY	2
43	5140033-42	FLAT WASHER	2
44	5140061-65	BEVEL GEAR	2
45	5140032-52	RING	2
46	5140179-66	SCREW & WASHER	1
47	N436291	BEVEL HANDLE	1
48	5140032-56	SCREW	1
49	5140032-57	LOCKWASHER	1
50	5140061-68	WASHER	1
51	5140032-66	CAP SCREW	1
52	5140179-67	SCREW	3
53	N440766	BEVEL POINTER	1
54	5140033-43	WASHER,EX TOOTH	1
55	5140032-67	WING SCREW	2
56	N434671	COVER	1
57	5140179-68	CANVAS	1

Parts List for DCS7485B Type 1

Item Number	Part Number	Description	Qty Required
58	5140179-69	PLATEN	1
59	5140179-70	PLATEN	1
60	5140135-26	SCREW AND WASHER	19
61	5140179-71	CANVAS	1
62	5140179-72	CANVAS	1
63	N434812	CRADLE	1
64	5140135-33	SCREW AND WASHER	2
65	5140061-77	SCREW	30
66	N434696	BLADE GUARD	1
68	N434674	CLAMP WASHER	1
69	429989-94	ARBOR NUT	1
70	5140032-77	PLATE	2
71	5140179-73	PLATE	1
72	N437343	GUARD BRACKET	1
73	N442868	SUPPORT PLATE	1
74	N452849	BRACKET	2
75	330019-13	SCREW,PLASTITE	20
76	5140179-74	FRONT PANEL	1
78	N441183	FOOT	4
79	5140135-64	SCREW AND WASHER	8
80	5140095-74	FLANGE NUT	8
81	5140179-75	LEFT PANEL	1
83	5140179-76	MITER GAGE HOLDER	1
84	5140135-74	SCREW AND WASHER	4
85	5140032-84	BUMPER	4
86	5140032-85	PLATE	4
87	N436199	WRENCH	2

Parts List for DCS7485B Type 1

Item Number	Part Number	Description	Qty Required
88	5140032-95	WING NUT	1
89	N446306	CARRY-HANDLE	1
90	N441177	PLATE	2
91	5140179-77	BRACKET	1
92	5140135-79	SCREW	5
93	N438026	BRACKET	1
94	5140032-13	NYLOCK NUT	2
100	N464191	GUARD	1
102	330016-15	FLAT WASHER	2
103	5140179-79	RETAINING RING	1
104	5140179-78	SPONGE	1
105	N434782	SPLITTER	1
110	N434670	ELEVATING SCREW	1
111	5140032-72	THRUST WASHER	2
112	5140032-73	BLOCK	1
113	5140032-75	WASHER	1
114	5140179-64	SPACER	1
115	5140033-40	DOWEL PIN	4
116	5140128-65	NUT	1
117	5140032-46	SHOULDER SCREW	1
118	5140032-47	KNOB	1
119	5140135-91	CAP SCREW	2
120	N441179	CAM	2
121	N441023	LABEL	1
122	N440453	SCALE LABEL	1
123	N461050	WARNING LABEL	1
124	5140032-80	SCREW	4

Parts List for DCS7485B Type 1

Item Number	Part Number	Description	Qty Required
125	5140135-73	SPRING	1
126	5140032-13	NYLOCK NUT	1
127	330016-27	WASHER	1
128	N461046	RATING LABEL	1
129	5140033-36	LABEL	1
152	5140032-21	DOWEL PIN	1
153	N440620	HANDLE	1
154	5140134-74	FLAT WASHER	1
155	5140032-25	NUT	1
157	1002774-00	SNAP RING	1
158	5140134-78	NYLOCK NUT	2
159	5140032-27	FLAT WASHER	3
160	5140032-28	FENCE KNOB	1
161	5140032-29	PINNION GEAR	2
162	5140032-31	BRACKET	2
163	5140118-01	BRACKET GAUGE	2
164	5140032-33	E-RING	2
165	5140032-34	DOWEL PIN	2
166	5140032-35	GEAR ROD	1
167	5140032-36	BEARING BLOCK	2
168	5140032-37	SPRING PLATE	2
181	5140032-17	ADJUSTING SHAFT	1
182	5140134-76	HEX NUT	1
183	5140135-11	SET SCREW	3
184	5140032-43	E-RING	1
185	5140032-06	FLAT WASHER	1
200	330019-24	SCREW PLASTITE	4

Parts List for DCS7485B Type 1

Item Number	Part Number	Description	Qty Required
202	330019-12	SCREW	2
204	330045-17	SCREW	4
209	N469850	ROTOR ASSY.	1
210	N453643	O-RING	1
211	700248-00	O RING	1
212	N434675	GEAR CASE	1
213	N442722	GASKET	1
214	N469847	ARBOR ASSEMBLY	1
215	330045-14	SCREW, TAPTITE	3
217	N435741	COVER	1
218	N440456	PIVOT PIN	1
219	000000-00	No Longer Available	1
220	000000-00	No Longer Available	1
221	N474607	STATOR & MODULE	1
222	N448766	TORSION SPRING	1
223	N445218	SWITCH PADDLE	1
224	N435742	COVER	1
225	N449833	CORD CLAMP	1
226	330019-03	SCREW, PLASTITE	1
227	N461735	SPRING	1
228	N091479	MOUNT- SPRING	1
230	N445217	SWITCH BEZEL	1
232	N474607	STATOR & MODULE	1
238	5140033-37	WARNING LABEL	1
253	5140033-45	SHEET METAL SCREW	4
258	5140134-56	PLATE	2
259	5140033-50	DOWEL PIN	2

Parts List for DCS7485B Type 1

Item Number	Part Number	Description	Qty Required
260	5140033-51	SPRING PLATE	2
261	5140134-58	PIN	2
284	5140134-60	SPRING CLIP	1
285	5140134-61	SCREW	2
286	5140134-62	STRAP CLAMP	1
299	A23334	SPRING	1
301	5140033-53	SCREW	4
305	A26204	CAM	1
306	A26206	SPRING	1
307	A26205	SCREW	1
400	A24519	WARNING LABEL	1
401	A26305	WARNING LABEL	1
602	5140032-02	LOCATING PIN	6
603	5140032-03	NUT	6
800	30301914-01	GREASE	1
800	429954-01	GREASE, 500GRAMS	1
800	429954-00	GREASE, 7LBS	1
856	DWE74911	STAND ASSY	1
856	DWAFV3824	24T SAW BLADE	1
856	DW7451	TABLESAW STAND	1
866	DCB606	FLEXVOLT BATTERY	1
867	N475920	BATTERY CAP	1
871	DCB118	CHARGER	1