



Parts List for DCST990B Type 1

Item Number	Part Number	Description	Qty Required
1	90603731	HOUSING ASSEMBLY	1
2	90605690	CAGE	1
3	90605691	CAGE	1
4	90605692	HANGER	1
5	90609272	T-NUT	1
6	90606556	LATCH BUTTON	1
7	90619743	LATCH KIT	1
8	90606949	CONTROL MODULE ASSY	1
9	90605114	SWITCH SUPPORT	1
10	90608663	WIRE HARNESS	1
13	90605769	ASSEMBLY- EJECTOR	1
14	330019-13	SCREW,PLASTITE	17
15	90609878	SCREW,LOCKING	2
16	90601032	EXTENTION POLE	1
17	90608944	DOWEL PIN	2
18	90602632	O-RING	3
19	90599031	SWITCH LINK	1
20	90603845	WIRE COVER	1
21	90603726	HANDLE ASSEMBLY	1
22	90601034	LOCK OFF BUTTON	1
23	90602633	LOCK OFF SPRING	1
24	90608942	PIVOT PIN	2
25	90599030	ACTUATOR,LEVER	1
26	90602634	ACTUATOR SPRING	1
27	90602320	ACTUATOR	1
28	N014681	DETENT SPRING	2
29	90600458	MOMENTARY SWITCH	1

Parts List for DCST990B Type 1

Item Number	Part Number	Description	Qty Required
30	330019-03	SCREW,PLASTITE	7
31	90603783	AUX HANDLE	1
32	90603784	HANDLE MOUNT	1
33	90608998	HANDLE CLAMP	1
34	608176-00	SCREW	4
35	330019-20	SCREW	2
36	330045-16	SCREW,TAPTITE	2
37	330045-13	SCREW,TAPTITE	1
39	90603415	GUARD ASSEMBLY	1
40	330045-14	SCREW, TAPTITE	7
41	90607066	SPINDLE LOCK PLATE	1
44	90599025	REPLACEMENT SPOOL	1
45	90609633	WIRE COVER	1
46	330016-15	FLAT WASHER	4
47	90615599	WASHER	2
101	90601733SV	GEAR CASE & BRG	1
102	90601734SV	GEAR CASE COVER ASSY	1
103	90612977SV	MOTOR ASSEMBLY	1
104	90617846SV	PCB ASSEMBLY	1
105	90612360	CABLE ASSEMBLY	1
106	330019-15	SCREW,PLASTITE	4
107	90614000	MOTOR END CAP	1
110	370023	NUT	1
117	90601087	SPOOL	1
121	90606555	BATTERY LATCH	1
122	90607453	SPRING SUPPORT	1
123	90606558	LATCH SPRING	2

Parts List for DCST990B Type 1

Item Number	Part Number	Description	Qty Required
150	90612052	RATING LABEL	1
151	90612053	WARNING LABEL	1
152	90612055	ID LABEL	1
856	DWO1DT802	TRIMMER LINE	1
856	DWO1DT801	TRIMMER LINE	1
866	DCB404	BATTERY PACK	1
871	DCB114	CHARGER	1