





Parts List for DH4240 Type 1

Item Number	Part Number	Description	Qty Required
1	5140095-08	MANIFOLD	1
2	5140095-09	SCREW	8
3	5140095-10	LOCK WASHER	10
10	5140095-53	VALVE CAP	1
11	15607	KIT VALVE	1
12	5140095-11	SCREW	8
13	5140095-12	BEARING COVER	1
14	5140095-13	OIL GAUGE	1
15	5140095-14	O-RING	2
16	5140095-15	BALL BEARING	1
17	5140095-54	OIL SEAL	1
18	5140095-16	CRANKCASE	1
19	5140095-17	DIPSTICK	1
22	5140095-18	GUIDE	3
23	5140095-19	CONNECTING ROD	3
24	5140095-20	O-RING	1
25	5140095-21	CRANKCASE COVER	1
26	5140095-22	SCREW	4
27	5140095-23	O-RING	1
28	5140095-24	PLUG	1
29	5140095-25	PIN	3
30	5140095-26	WASHER	3
31	5140095-27	RING	3
32	5140095-28	O-RING	3
33	5140095-29	PLUNGER CERAMIC	3
34	5140095-30	BUSHING	3
35	5140095-31	NUT	3

Parts List for DH4240 Type 1

Item Number	Part Number	Description	Qty Required
43	5140095-56	RETAINER	1
44	5140095-55	SEAL KIT	1
55	5140095-32	RETAINING RING	1
57	5140095-34	SCREW	1
58	5140095-35	ROLLER BEARING	1
61	5140095-36	FLANGE	1
62	5140095-37	OIL SEAL	1
63	5140095-38	WASHER	4
64	5140095-39	SCREW	4
91	5140095-58	UNLOADER KIT	1
104	5140095-57	UNLOADER KIT	1
120	5140095-40	O-RING	1
121	5140095-41	NIPPLE	1
122	5140095-42	FITTING	1
123	5140095-43	O-RING	1
130	5140095-44	O-RING	1
131	5140095-45	NOZZLE	1
132	5140095-46	O-RING	1
133	5140095-47	SPRING	1
134	5140095-48	BALL	1
135	5140095-49	O-RING	1
142	5140095-50	INJECTOR	1
144	5140095-51	BOLT	1
145	A08935	INJECTOR CHEMICAL	1
201	5140094-91	ENGINE	1
202	5140094-92	PUMP ASSEMBLY	1
204	5140094-93	HOSE ADAPTER	1

Parts List for DH4240 Type 1

Item Number	Part Number	Description	Qty Required
205	5140094-94	COUPLER	1
206	5140094-95	VALVE THERMAL RELIEF	1
207	5140094-96	HOSE CHEMICAL	1
208	5140094-97	FRAME	1
209	5140094-98	HANDLE ASSY.	1
213	5140094-99	NOZZLE HOLDER RUBBER	1
214	5140095-00	HARDWARE KIT	1
217	5140095-01	HARDWARE KIT	1
220	5140095-02	WHEEL KIT	2
223	5140095-03	FOOT	2
226	5140095-04	NOZZLE SET	1
227	5140095-05	GUN	1
228	5140095-06	LANCE	1
229	5140095-07	HOSE	1