













Parts List for DP3850 Type 1

Item Number	Part Number	Description	Qty Required
5	5140046-15	SCREW	4
6	429898-05	LOCKWASHER,M8	4
7	1356534	FLAT WASHER	4
10	5140046-16	O-RING	1
11	5140043-87	OIL SEAL	1
20	5140046-17	CONNECTING ROD	3
32	A03525	CAP OIL FILLER CAT 5	1
33	P186	ORING CAT 14179	2
37	92241	GAUGE	1
38	P262	SEAL SIGHTGLASS OIL	1
48	A03527	PLUG DRAIN CAT 44842	1
64	5140046-18	PIN	3
65	5140046-19	ROD	3
70	V155	SEAL OIL CAT 47215	3
75	5140046-20	SLINGER	3
90	5140046-21	PLUNGER	3
98	5140046-22	SEAL KIT	1
99	5140046-23	RETAINER	3
100	5140046-24	RETAINER	3
101	5140046-05	HANDLE	1
102	5140046-28	CAP	1
103	5140046-29	LOCKING NUT	1
104	5140046-30	SET SCREW	1
108	5140046-31	SPRING	1
110	5140046-33	SPRING RETAINER	1
120	5140046-25	SEAL	3
123	5140046-34	VALVE RETAINER	1

Parts List for DP3850 Type 1

Item Number	Part Number	Description	Qty Required
126	5140046-35	WASHER	1
135	5140046-36	BALL / VALVE ASSY CA	1
136	5140046-37	SEAT	1
138	5140046-38	SEAT	1
139	P599	ORING CAT 13963	1
143	5140046-39	CHECK VALVE	1
144	5140046-40	SPRING	1
160	5140046-26	VALVE KIT	1
168	5140046-32	O-RING KIT	1
169	5140046-27	INJECTOR	1
182	5140043-78	O-RING	1
188	5140043-98	SCREW	6
201	A08642	ENGINE	1
202	D23124	LABEL,WARNING	1
203	A14552	LABEL HOT SURFACE	1
205	A19990	PUMP	1
206	000000-00	No Longer Available	1
208	A11349	BOLT .375-16X1.25 FL	4
209	A13853	FRAME	1
210	N000530	HANDLE	1
211	A18466	NUT	4
212	18300	BOLT .375-16X1.75 FL	4
213	A00253	TIRE PNEU 12 X 4 STU	2
214	D30249	COLLER AXLE SET SCRE	2
215	A16267	LABEL WARNING	1
216	A16268	LABEL WARNING	1
217	A16269	LABEL WARNING	1

Parts List for DP3850 Type 1

Item Number	Part Number	Description	Qty Required
218	H140	HOSE ASSY CHEMICAL	1
219	D21436	SCREW .250-20X.750 U	2
220	D21437	NUT.250-20 FLANGEHEA	2
221	D22268	ISOLATOR RECESSED RU	2
222	NCT001	TOOL NOZZLE CLEANING	1
223	D30374	NOZZLE HOLDER RUBBER	1
224	17730	NOZZLE KIT 4.5 5 PAC	1
225	5140095-05	GUN	1
226	N000579	HOSE ASSEMBLY	1
227	D26148	WAND EXTENSION	1
228	A19985	SOCKET QUIK CONNECT	2
229	D30492	BUTTON SNAP .302 DIA	2
230	000000-00	No Longer Available	1
231	17086	REEL HOSE 100 CAP 3/	1
232	A16255	HANDLE	1
233	16087	NUT .313-18 UNC FLAN	4
234	F064	SCREW .313-18X1.00 H	4
238	F039	PLUG QUICK CONNECT F	1
239	17658	VALVE THERMAL RELIEF	1
240	A21252	LANCE EXT	1
241	16364	PLUG 3/8 NPT	1
242	16829	ADAPTER 1/2	1
246	F179	ORING 1/4 QC	1
247	90510475	EXTENSION	1
250	90509698	SIDE HANDLE	1
251	90510816	NAMEPLATE	1
252	90510282	WARNING LABEL	1

Parts List for DP3850 Type 1

Item Number	Part Number	Description	Qty Required
253	90510283	WARNING LABEL	1
254	D24875	NIPPLE CLOSE 1/2 NPT	1
260	A15412	SCREW	4
261	A14647	PLATE	1
401	285805-44	GASKET	1
402	285807-16	ELEMENT	1
403	285807-17	FILTER	1
404	285807-18	COVER	1
405	285800-05	GROMMET	1
406	285805-48	COLLAR	2
407	285800-07	COLLAR	1
408	285807-20	ELBOW	1
409	285800-46	NUT	2
411	285800-11	WING NUT	2
412	285807-19	NOSE	1
413	285805-50	BOLT	1
419	285803-03	FAN	1
420	285807-01	FLYWHEEL	1
421	285803-05	NUT	1
422	285803-06	KEY	1
423	285807-00	PULLEY	1
424	285803-08	WEIGHT	1
425	285806-95	CRANKSHAFT	1
426	285806-09	BALL BEARING	1
427	285806-10	CAMSHAFT	1
428	285803-11	PUSH ROD	2
429	285803-12	ARM	2

Parts List for DP3850 Type 1

Item Number	Part Number	Description	Qty Required
430	285803-13	LIFTER	2
431	285800-18	PIVOT	2
432	285800-19	SPRING	1
433	285803-14	INTAKE VALVE	1
434	285803-15	VALVE	1
435	285803-16	SPRING	2
436	285803-17	RETAINER	1
437	285803-18	RETAINER	1
438	285803-19	SEAT	1
439	285803-20	ROTATOR VALVE	1
440	285803-21	PLATE	1
441	285800-27	BOLT	2
442	285800-28	NUT	2
443	285803-22	SEAL	1
447	285805-51	GASKET SET	1
448	285803-76	VALVE SET	1
449	285803-77	FLOAT SET	1
450	285805-61	CHAMBER SET	1
451	285800-51	SET SCREW	1
452	285800-52	SET SCREW	1
453	285800-53	SET SCREW	1
454	285806-82	CHOKE SET	1
455	285806-83	CARBURETOR	1
456	285800-56	SCREW	1
457	285806-84	NOZZLE	1
458	285800-58	O-RING	1
459	285806-85	INSULATOR	1

Parts List for DP3850 Type 1

Item Number	Part Number	Description	Qty Required
460	285806-05	GASKET	1
461	285805-56	SPACER	1
462	285806-04	GASKET	1
463	285800-63	LEVER	1
464	285800-64	LEVER	1
465	285800-65	PLATE	1
466	285800-66	SPRING	1
467	285800-67	GASKET	1
468	285800-68	CUP	1
469	285800-69	SCREW	2
470	285800-70	PIN	1
471	285806-87	MAIN JET	1
471	285806-86	MAIN JET	1
471	285805-59	MAIN JET	1
472	285804-58	JET	1
473	285802-81	OIL SEAL	1
474	285801-10	O-RING	1
475	285801-11	NUT	1
476	285802-82	WASHER	2
477	285802-83	LOCK PIN	1
478	285801-14	BOLT	2
479	285802-70	BEARING	1
480	285801-22	OIL ALERT UNIT	1
481	285800-41	BOLT	1
482	285802-85	CYLINDER HEAD	1
483	285802-86	GUIDE	1
484	285802-87	GUIDE	1

Parts List for DP3850 Type 1

Item Number	Part Number	Description	Qty Required
485	285802-88	CLIP	1
486	285806-22	GASKET	1
487	285802-90	COVER	1
488	285802-91	GASKET	1
489	285802-92	BOLT	1
490	285806-97	BOLT	2
491	285803-51	TUBE	1
492	285802-95	BOLT	2
493	285802-96	WASHER	1
494	285802-97	PIN	1
495	285804-79	BOLT	4
496	285800-98	SPARK PLUG	1
497	285803-39	STARTER ASSY.	1
498	285803-39	STARTER ASSY.	1
499	285803-41	PULLEY	1
500	285803-42	RATCHET	2
501	285803-43	SPRING	1
502	285803-44	SPRING	1
503	285804-38	BOLT	2
504	285803-46	RETAINER	1
505	285803-45	SPRING	1
506	285803-48	GRIP	1
507	285803-49	ROPE	1
508	285802-71	OIL SEAL	1
510	285803-50	SCREW	1
511	285802-79	WASHER	1
533	285801-33	RUBBER TUBE	1

Parts List for DP3850 Type 1

Item Number	Part Number	Description	Qty Required
534	285801-34	JOINT	1
535	285807-02	TANK	1
536	285807-03	FUEL CAP	1
537	285807-04	GASKET	1
538	285801-10	O-RING	1
539	285803-72	NUT	2
540	285801-40	HOSE	1
541	285801-41	CLIP	4
542	285805-87	BOLT	2
543	285801-53	BOLT	3
547	285803-84	COLLAR	1
567	285807-05	MUFFLER	1
568	285807-06	PROTECTOR	1
569	285807-07	PROTECTOR	1
570	285805-92	EXHAUST PIPE	1
571	285807-08	CAP	1
572	285807-09	GASKET	1
573	285807-10	SPARK ARRESTOR	1
574	285805-95	GASKET	1
575	285800-41	BOLT	1
576	285801-71	SCREW	5
577	285801-72	SCREW	3
578	285803-72	NUT	5
579	285807-12	CAUTION LABEL	1
580	285807-11	SCREW	1
583	285804-86	IGNITION COIL	1
584	285801-30	CAPACITOR ASSY	1

Parts List for DP3850 Type 1

Item Number	Part Number	Description	Qty Required
588	285804-24	GROMMET	1
589	285804-88	WIRE	1
593	285802-29	BOLT	2
594	285806-23	EMBLEM	1
599	285805-86	FILTER	1
602	285806-93	COVER ASSEMBLY	1
603	285804-36	GASKET	1
604	285800-77	CAP ASSY.	1
605	285802-74	CAP ASSY.	1
606	285800-78	GASKET	2
607	285802-64	GOVERNOR	1
608	285802-66	WEIGHT	2
609	285802-65	HOLDER	1
610	285802-67	PIN	1
611	285802-68	SLIDER	1
612	285801-07	CLIP	1
613	285802-73	DOWEL PIN	2
614	285802-71	OIL SEAL	1
615	285801-12	WASHER	1
616	285802-72	BOLT	1
617	285802-70	BEARING	1
618	285802-69	BEARING	1
620	285805-77	KEY	1
626	285805-80	CLIP	1
629	285806-90	CONTROL ASSY	1
630	285806-88	ARM	1
631	285803-25	ROD	1

Parts List for DP3850 Type 1

Item Number	Part Number	Description	Qty Required
632	285803-26	SPRING	1
633	285806-89	SPRING	1
634	285806-91	CONTROL LEVER	1
635	285800-35	SPRING	1
636	285805-66	WASHER	1
637	285800-37	HOLDER	1
638	285805-67	SPACER	1
639	285800-39	SPRING	1
640	285805-69	SPRING	1
641	285800-41	BOLT	2
642	285800-42	BOLT	1
643	285800-43	NUT	1
644	285806-92	SCREW	1
645	285802-21	SCREW	1
646	285800-46	NUT	1
654	285806-13	RING SET	1
654	285806-14	RING SET	1
654	285806-12	RING SET	1
654	285806-24	RING SET	1
655	285806-17	PISTON	1
655	285806-18	PISTON	1
655	285806-15	PISTON	1
655	285806-16	PISTON	1
656	285807-15	PIN	1
657	285806-20	CONNECTING ROD	1
657	285806-19	CONNECTING ROD	1
658	285803-37	BOLT	2

Parts List for DP3850 Type 1

Item Number	Part Number	Description	Qty Required
659	285803-38	CLIP	2
660	285806-98	COVER	1
661	285803-00	SHROUD	1
662	285806-99	SWITCH ASSY.	1
663	285800-41	BOLT	6
664	285805-82	CLIP	1
665	A08642	ENGINE	1
666	285802-76	SWITCH ASSY	1
667	285802-77	SHAFT	1
675	285801-75	LABEL	1
676	285805-88	LABEL	1
678	285801-78	LABEL	1