



REPLACEMENT PARTS

| Ref. No. | Part No. | Description | Ref. No. | Part No. | Description |
|----------|-----------------|-------------------------------------|----------|-----------------|-----------------------------------|
| * | 15-825 | Belt Guard Complete, Const. Of: | 68 | 902-01-010-1282 | 1/2"-13 Hex Jam Nut |
| 1 | 402-04-354-5013 | Belt Guard, Incl: | 69 | 928-08-011-8868 | Pinion Clock Spring |
| 2 | 901-06-450-2252 | #4 X 3/16" Drive Screw | 70 | 402-04-031-5001 | Clock Spring Housing |
| 3 | Nameplate | By Request Only | 71 | 902-01-281-7295 | 1/4"-20 Hex Lock Nut |
| 4 | 928-03-011-8878 | Spring R.H. | 72 | 931-04-051-4071 | Ball Crank |
| 5 | 902-03-010-2971 | Tinnerman Nut | 73 | 402-04-112-5001 | Adjusting Screw |
| 6 | 928-03-011-8879 | Spring L.H. | 74 | 902-01-200-9706 | 1/4"-20 Hex Nut |
| 7 | 901-01-060-0605 | 5/16-18 X 1/2" Hex Hd. Cap Scr. | * | 402-04-377-5003 | Quill Ass'y., Const. Of: |
| 8 | 402-04-354-5014 | Guard Pan, Incl: | 76 | 904-15-010-7411 | Retaining Ring |
| 9 | 402-04-106-5001 | Bumper | 77 | 920-04-020-5384 | Bearing |
| 10 | 902-01-120-1203 | #10-32 Hex Nut | 78 | 928-06-011-4127 | Spring Washer |
| 11 | 931-02-051-4074 | Lock Knob | 79 | 402-04-077-5002 | Quill |
| 12 | 901-02-050-0732 | #10-32 X 7/8" Fil. Hd. Scr. | 80 | 902-07-020-7176 | Bearing Nut |
| 15 | 41-832 | Motor Pulley, 1/2" Bore, Incl: | 81 | 402-04-385-5006 | Spindle Ass'y., Incl: |
| 16 | 901-04-150-6215 | 1/4-20 X 3/8" Hex Soc. Set Scr. | 82 | 904-15-010-7410 | Retaining Ring |
| 15 | 41-833 | Motor Pulley, 5/8" Bore, Incl: | 83 | 920-04-020-5384 | Bearing |
| 16 | 901-04-150-6215 | 1/4-20 X 3/8" Hex Soc. Set Scr. | 85 | 908-00-000-3769 | Special Gasket |
| 17 | 902-01-010-1300 | 5/16-18" Hex Nut | 86 | 402-04-314-5007 | Stop Collar, Incl: |
| 18 | 904-01-010-1620 | 11/32 X 11/16 X 1/16" Washer | 87 | 901-04-090-0112 | #10-32 X 1/2" Headless Set Scr. |
| 19 | 902-03-000-2951 | Tinnerman Speed Nut | 88 | 901-01-060-0622 | 1/4-20 X 2" Hex Hd. Cap Scr. |
| 20 | 901-01-060-0609 | 5/16-18 X 1-1/2" Hex Hd. Cap Scr. | 89 | 931-02-141-4087 | 1/4"-20 Special Nut |
| 22 | 402-04-072-5001 | Motor Plate | 90 | 902-01-010-5900 | 3/8"-16 Hex Nut |
| 23 | 901-11-020-0834 | 5/16-18 X 3/4" Carriage Bolt | * | 402-04-408-5005 | Stop Rod Ass'y., Const. Of: |
| 24 | 904-01-010-1620 | 11/32 X 11/16 X 1/16" Steel Washer | 91 | 402-04-012-5001 | Holding Nut |
| 25 | 400-00-057-5002 | Head Casting | 92 | 901-04-260-1534 | #6-32 X 1/4" Thumb Screw |
| 26 | 932-01-000-2851 | Bumper | 93 | 402-04-088-5005 | Micro-Nut |
| 27 | 402-04-088-5004 | Motor Plate Plunger | 94 | 402-04-108-5007 | Stop Rod |
| 28 | 928-01-021-4110 | Spring | 96 | 15-830 | Chuck, Incl: |
| 29 | 931-03-991-9032 | Hand Knob | 97 | 1200490 | Key |
| 30 | 907-01-050-5239 | Oiler | 98 | 15-833 | #2 Morse Taper Spindle Adapter |
| 32 | 49-093 | V-Belt (44-3/8" O.C.) | 100 | 15-838 | Spanner Wrench |
| 35 | 926-07-992-0588 | Spring Pulley | 101 | 48-273 | 1/8" Hex Soc. Wrench |
| 36 | 901-04-150-6215 | 1/4-20 X 3/8" Hex Soc. Set Scr. | 102 | 48-245 | 5/32" Hex Soc. Wrench |
| 37 | 927-03-010-2668 | 3/16 X 3/16 X 1-3/4" Key | 103 | 40-526 | Double End Wrench |
| * | 402-04-405-5006 | Sleeve Ass'y., Const. Of: | 104 | 43-524 | Double End Wrench |
| 38 | 402-04-105-5006 | Sleeve | 105 | Cannot Furnish | Double End Wrench |
| 39 | 904-15-010-7025 | Retaining Ring | 110 | 15-010 | Support, Incl: |
| 40 | 920-04-020-5360 | Bearing | 111 | 901-01-060-0641 | 7/16-14 X 3-1/2" Hex Hd. Cap Scr. |
| 41 | 402-04-079-5001 | Retainer | 112 | 902-01-040-1004 | 7/16"-14 Hex Nut |
| 42 | 928-06-010-7352 | Spring Washer | * | 15-809 | Table Complete, Const. Of: |
| 43 | 402-03-105-5001 | Sleeve | 113 | 901-11-010-7862 | 1/2-13 X 3-1/4" Sq. Hd. Bolt |
| 44 | 901-01-060-0621 | 1/2-13 X 5-1/2" Hex Hd. Cap Scr. | 114 | 402-04-105-5005 | Sleeve |
| 45 | 902-01-020-5435 | 5/16"-18 Hex Nut | 115 | 901-01-060-0643 | 1/2-13 X 3-3/4" Hex Hd. Cap Scr. |
| 46 | 901-04-010-0378 | 5/16-18 X 7/8" Sq. Hd. Set Scr. | 116 | 402-04-314-5002 | Table Bracket, Incl: |
| 47 | 402-04-106-5009 | Pinion Shaft | 117 | 402-04-072-5002 | Scale |
| 48 | 402-04-409-5002 | Collar for Pinion Shaft, Incl: | 118 | 901-06-450-2849 | #6 X 1/4" Drive Screw |
| 49 | 921-01-010-0028 | 1/4" Steel Ball | 119 | 931-04-991-3461 | Lock Bolt |
| 50 | 928-01-021-3378 | Spring | 120 | 904-10-031-3893 | Washer |
| 51 | 931-02-121-4081 | Lock Knob | 121 | 402-04-091-5001 | Table |
| 52 | 931-01-011-3519 | Handle Ball | 122 | 904-01-010-1636 | 17/32 X 1-1/16" X .095 Washer |
| 53 | 402-05-108-5004 | Hand Lever | 123 | 902-01-100-1028 | 1/2"-13 Hex Nut |
| 54 | 931-03-991-9031 | Hand Knob | 124 | 402-02-071-5001 | Index Pin |
| 55 | 902-01-010-1232 | 7/16"-20 Hex Nut | 125 | 15-804 | Column (Bench Model) |
| 56 | 901-03-013-1026 | 1/4-20 X 1-3/4" Fil. Hd. Scr. | 125 | 15-806 | Column (Floor Model) |
| 57 | 438-01-021-0081 | Switch Bracket | 126 | 402-04-005-5006 | Base (Floor Model) |
| 58 | 901-06-120-3016 | #6 X 7/16" Rd. Hd. Self-Tapping | 127 | 901-04-150-1112 | 3/8-16 X 1/2" Hex Soc. Set Scr. |
| 59 | 402-04-031-5002 | Switch Opening Cover | 128 | 402-04-005-5001 | Base (Bench Model) |
| 60 | 901-06-120-3015 | #6 X 1/4" Rd. Hd. Self-Tapping Scr. | 129 | 901-04-150-1107 | 5/16-18 X 1" Hex Soc. Set Scr. |
| 65 | 402-03-027-5002 | Column Clamp | | | |
| 66 | 402-03-105-5003 | Clamp Sleeve | * | NOT SHOWN | |
| 67 | 904-01-031-2905 | 33/64 X 7/8 X 1/16" Washer | | | |