














120





Parts List for DW079LR Type 1

Item Number	Part Number	Description	Qty Required
1	5140204-74	PAN HEAD SCREW	2
2	5140204-75	PRISM COVER	1
3	000000-00	No Longer Available	1
5	5140204-76	STRAP	1
12	N491789	ADAPTER	2
14	5140204-90	WEDGY	1
15	5140204-78	SEAT	1
19	N482090	REMOTE CONTROL	1
20	N528000	ADAPTER	1
21	N482092	LASER DETECTOR	1
22	DW0730	LASER TARGET CARD	1
32	N482094	CLAMP	1
41	N528005	BRACKET	1
88	5140204-92	GLASS	1
89	5140204-57	PAN HEAD SCREW	4
90	5140204-91	GLASS	1
91	5140204-80	FRAME	1
92	5140204-81	GASKET	1
93	DW0714	ENHANCEMENT GLASSES	1
94	5140204-83	GASKET	1
95	5140204-59	PAN HEAD SCREW	8
96	5140204-60	TOP COVER HANDLE	1
97	5140204-84	PC BOARD ASSY	1
98	5140204-61	GASKET	2
99	5140204-62	RUBBER MAT	8
100	5140204-63	HOUSING	1
101	5140204-85	MEMBRANE	1

Parts List for DW079LR Type 1

Item Number	Part Number	Description	Qty Required
102	5140204-65	PAN HEAD SCREW	10
103	5140204-66	BATTERY COVER	1
104	5140204-67	RUBBER MAT	8
107	5140204-86	GLASS	1
109	5140204-87	BUZZER	1
110	5140204-72	TRANSITION	1
111	5140204-73	BOTTOM COVER	1
113	5140204-71	HOLDER	2
114	5140204-69	COUNTERSUNK SCREW	4
120	5140204-93	LASER ASSEMBLY	1
861	P910190	LATCH	2
861	H1500082520	LATCH	2
861	H2500531	COVER PLATE	1
861	N429655	KIT BOX	1
861	H1400196	HANDLE	1
866	DCB203	BATTERY PACK	1
871	DCB115	CHARGER	1