



## Parts List for DWE4887 Type 1

Item Number	Part Number	Description	Qty Required
1	330065-25	SCREW	4
2	N132864	BAFFLE	1
3	N232485	FIELD	1
4	N122019	FIELD CASE	1
5	N122021	END HANDLE	1
6	330005-01	PROTECTOR,CORD	1
7	N017839	SCREW	1
8	330072-98	CORD/8FT/18-2SJ	1
9	N260662	SPRING	1
10	N327459	SWITCH	1
11	N097696	BRUSH	2
13	N097703	BRUSH SPRING	2
14	N097702	BRUSH BOX ASSY	1
15	N167600	BRUSH BOX	1
16	593478-00	SCREW	2
17	619328-00	CLAMP	1
18	562097-00	SCREW	1
19	N221693	ROLL PIN	1
20	562210-00	SPRING	1
21	N124292	LOCK-ON BUTTON	1
25	N232486	PADDLE ASSY.	1
26	N275347	DRIVER	1
27	N275349	COUPLING	2
28	N286522	SNAP RING	1
29	N175104	BALL BEARING	1
30	N119639	O-RING	1
31	N283650	STATOR	1

## Parts List for DWE4887 Type 1

Item Number	Part Number	Description	Qty Required
32	N213812	SLINGER	1
34	N130916	BALL BEARING	1
35	N101228	SLINGER	1
36	641823-00	BEARING CUP	1
37	330065-09	SCREW	4
38	N403431	NUT	1
39	N383609	1/4 COLLET	1
40	N287179	NOSE	1
41	N403099	OUTPUT SHAFT	1
42	638229-00	SLINGER	1
43	330003-64	BALL BEARING	1
45	N398026	O-RING	2
46	N403098	NOSE	1
47	N308579	O-RING	1
48	330003-96	BALL BEARING	1
49	N184706	RETAINING RING	1
50	N319739	RATING LABEL	1
51	N149175	ID LABEL	1
52	N119716	WARNING LABEL	1
53	N332459	WRENCH	2
54	N403100	WASHER	1
55	878190	BEARING	1
60	444262-00	TERMINAL	2
103	N386327	ARMATURE ASSEMBLY	1