





Parts List for DXCMV7518075 Type 0

Item Number	Part Number	Description	Qty Required
1	5140172-91	DRAIN VALVE	1
1	5140119-72	O-RING	2
1	5140119-71	BUSHING	1
1	5140119-74	BUSHING	1
2	5140156-26	NIPPLE	1
3	5140153-33	WASHER	8
4	5140176-84	PUMP ASSEMBLY	1
5	5140176-23	SCREW	4
6	5140153-32	WASHER	8
7	5140153-26	NUT	8
8	5140119-67	BLEEDER TUBE	1
9	5140119-64	ELBOW	1
10	5140204-46	CHECK VALVE	1
11	5140176-24	TRANSFER TUBE	1
12	5140176-25	SCREW	4
13	5140176-26	MOTOR	1
14	5140176-27	KEY	1
15	5140153-40	BRACKET	2
16	5140153-35	SCREW	4
17	5140153-42	BELT GUARD	1
18	5140169-49	BELT GUARD	1
19	5140176-31	PULLEY	1
20	5140176-32	V-BELT	2
21	5140153-39	U-NUT	4
22	5140153-29	SCREW	6
23	5140153-36	SCREW	2
24	5140153-28	LOCK NUT	2

Parts List for DXCMV7518075 Type 0

Item Number	Part Number	Description	Qty Required
26	5140176-33	MAGNETIC STARTER	1
27	5140183-51	BRACKET	1
28	5140119-90	STRAIN RELIEF	1
29	5140176-35	CORD	1
30	5140176-36	CORD	1
31	5140176-37	STRAIN RELIEF	1
32	5140119-13	WARNING LABEL	1
33	5140119-81	WARNING LABEL	1
34	5140119-63	CONNECTOR	2
35	5140204-47	COMPRESSION NUT	2
36	5140176-38	BUSHING	1
37	5140119-14	WARNING LABEL	1
38	5140176-39	HUB	1
40	5140176-40	STRAIN RELIEF	1
41	5140169-53	SHIELD	1
42	5140176-42	WASHER	4
43	5140119-55	GAUGE	1
44	5140121-87	PRESSURE SWITCH	1
45	5140176-43	WARNING LABEL	1
46	5140119-91	PRESSURE RELIEF VALV	1
47	5140119-58	STRAIN RELIEF	1
48	5140119-57	SCREW	1
49	5140119-60	VALVE, BLEEDER	1
50	5140176-44	PLUG	1
51	5140156-22	BOLT	2
52	5140176-45	WASHER	2
53	5140153-27	NUT	2

Parts List for DXCMV7518075 Type 0

Item Number	Part Number	Description	Qty Required
54	5140153-29	SCREW	2
103	5140176-48	HEAD BOLT	9
104	5140153-51	LOCK WASHER	22
105	5140176-49	CYLINDER HEAD	1
106	5140176-50	GASKET	1
109	5140176-51	GASKET	1
113	5140176-52	GASKET	1
114	5140176-53	CONNECTOR	1
115	5140176-54	COMPRESSION NUT	1
116	5140176-55	PISTON	1
117	5140176-56	WRIST PIN	1
118	5140176-57	PISTON	1
119	5140176-58	WRIST PIN	1
120	5140176-59	RETAINING RING	4
121	5140176-60	CYLINDER	1
122	5140176-61	GASKET	1
123	5140176-62	NUT	6
124	5140176-63	BOLT	6
125	5140176-64	CONNECTING ROD ASSY.	2
127	5140176-65	BEARING	2
128	5140176-66	NEEDLE BEARING	2
132	5140153-68	BREATHER CAP	1
133	5140153-69	CONNECTOR	1
134	5140176-67	BREATHER TUBE	1
135	5140153-71	BOLT	6
136	5140153-72	REAR BEARING CARRIER	1
137	5140153-73	GASKET	1

Parts List for DXCMV7518075 Type 0

Item Number	Part Number	Description	Qty Required
138	5140153-74	FILTER	1
139	5140153-75	SIGHT GLASS	1
140	5140153-76	PLUG	1
141	5140176-68	CRANKCASE	1
142	5140153-78	BEARING	2
143	5140176-69	CRANKSHAFT	1
144	5140153-80	KEY	1
145	5140176-70	OIL SEAL	1
146	5140176-71	FLYWHEEL	1
147	5140153-83	WASHER	1
148	5140153-84	WASHER	1
149	5140153-85	BOLT	1
150	5140190-48	INTERCOOLER	1
150	5140176-24	TRANSFER TUBE	1
151	5140153-87	PRESSURE RELIEF VALV	1
152	5140176-73	ELBOW	1
154	5140176-75	VALVE PLATE ASSEMBLY	1
155	5140176-76	RING SET	1
156	5140176-77	RING SET	1
157	5140176-78	PIPE CAP	1
158	5140176-79	NIPPLE	1
159	5140156-33	NUT	1
160	5140176-80	WASHER	1
161	5140176-81	BOLT	1
162	5140177-53	NIPPLE	1
163	5140177-54	ELBOW	1
163	5140176-74	ELBOW	1

Parts List for DXCMV7518075 Type 0

Item Number	Part Number	Description	Qty Required
164	5140177-55	FILTER CANN. ASSY	1
164	5140176-46	FILTER ASSEMBLY	1
165	5140176-82	GASKET SET	1
166	5140176-83	OVERHAUL KIT	1
167	5140177-56	FILTER	1
167	5140176-47	FILTER ELEMENT	1