



## PARTS

EC510

ITEM NO.	CODE NO.	DESCRIPTION	NO. USED	REMARKS
1	887496	JOINT	1	
2	887516	RILSAN HOSE	1	
3	887515	PRESSURE SWITCH	1	
4	881511	JOINT	1	
5	881652	SAFETY VALVE 1/4" 170 PS	1	
6	885446	2" PRESSURE GAUGE 1/4"	1	
7	881508	1-1/2" METAL PRESSURE GAUGE	1	
8	887499	MANIFOLD	1	
9	191051	1/4"NPTMX1/4"IND QUICK COUPLER 1EACH	2	
10	887520	SCREW	7	
11	881573	WASHER	4	
12	887505	FOOT	4	
13	887510	TANK	1	
14	882610	DISCHARGE TAP 1/4"	1	
15	887522	CHECK VALVE	1	
16	887509	LOWER SPACER	1	
17	887507	UPPER SPACER	2	
18	887508	UPPER COVER SPACER	2	
19	887497	PUMP UNIT	1	
20	887931	OGIVE	1	
21	887932	NUT	1	
22	887514	INFEED HOSE	1	
23	887933	NUT	1	
24	887512	CONVEYOR	1	
25	887350	SCREW OIL DRAIN	1	
25A	887935	WASHER	1	
25C	881401	SELF LOCKING NUT	1	
26	887511	COVER SUPORT	1	
27	881657	SCREW	1	
28	881604	SCREW	1	
29	887513	EXAGONAL SUPORT	2	
30	887501	REAR COVER	1	
31	887962	LOWER HANDLE	1	INCLUDES ITEM 34
32	887939	SCREW	2	
33	881595	SCREW	4	
34	887962	UPPER HANDLE	1	INCLUDES ITEM 31
35	887495	SCREW	5	
36	887500	FRONT COVER	1	
37	887506	PRESSURE SWITCH / MOTOR CABLE	1	
38	887941	POWER CORD	1	
39	887504	LOWER MOTOR SPACER	1	
40	884444	SCREW	1	
41	887109	WASHER	1	
		***** PUMP UNIT *****		
1	887498	CONVEYOR(UL-V0)	1	
2	887523	F3001 MOTOR SET 120V/60HZ	1	
3	887524	O-RING VALVE PLATE	1	
4	887525	VALVE PLATE COMPONENT	1	
5	887526	GASKET	1	
6	887527	HEAD	1	
7	887528	VALVE PLATE+SET OF GASKETS	1	
8	887529	SCREW(M5x20)	4	
9	887530	CYINDER	1	
10	887073	SCREW	1	
11	887532	RING-SUPPORT	1	
12	887533	PISTON RING	1	
13	887534	CONNECTION ROD	1	
14	887535	CON ROD/PISTON KIT	1	
15	887536	SCREW M10	1	
16	887537	BELT	1	

