



Parts List for EM1500 Type 3

Item Number	Part Number	Description	Qty Required
1	90601830	MOTOR ASSEMBLY	1
2	90601646-01	DECK ASSEMBLY	1
3	90579523	SCREW	1
4	90563941	BRAKE	1
5	90560309	GEAR BOX ASSY	1
6	90605108	OUTPUT GEAR	1
7	90560308	V-BELT	1
9	241658-03	RING,PUSH	2
10	90600212	FLAP	1
14	747329	SCREW	32
15	90563921-01	CLIP	1
18	90603925	HANDLE	1
20	90600030	GRASS BAG	1
21	90600031	FRAME,GRASS BAG	1
29	90603926	HANDLE	1
30	90571019-01	LOWER HOOK	2
31	90589823	SCREW	4
32	90566704-03	GRASSFLAP	1
33	90569681	EXTENSION SPRING	1
35	90574276	FASTENER	4
36	90600261-01	BAFFLE	1
37	90577039	REAR WHEEL	2
38	90561676-01	PLASTIC COVER	1
39	90600247	SHAFT	1
41	90577037	FRONT WHEEL	2
42	90560001	PLASTIC COVER	1
43	90569293	RIGHT FASCIA	1

Parts List for EM1500 Type 3

Item Number	Part Number	Description	Qty Required
44	90567331-01	FRONT HANDLE	1
46	90561677	PLASTIC COVER	1
47	90569292	LEFT FASCIA	1
48	90579431	RETAINING RING	1
49	90562575	CONNECTING ROD	1
50	90579432	RETAINING RING	1
51	90567592-02	PLASTIC COVER	1
52	90566707	HEIGHT ADJUST COVER	1
53	90577141-01	COVER ASSEMBLY	1
54	90563022-01	MOWER CAP	1
55	90561651	AXLE	1
56	90570279-02	HANDLE	1
57	90604378-01	BOLT & NUT	1
58	90571059	TORSION SPRING	1
63	90561984	PAD	1
64	90571573	BRAKE SPRING	1
65	90560645-02	BLADE	1
69	90568882-01	SLIDER	1
71	90561605	AXLE	1
72	330016-18	WASHER	1
86	90605101	ROCKER SWITCH	1
89	90601714	CABLE	1
91	90601713	CORDSET	1
93	90599943-01	HOUSING SET	1
94	90603735	CABLE CLAMP	2
96	90604628	COUPLING	1
97	90604868	BLADE SPACER	1

Parts List for EM1500 Type 3

Item Number	Part Number	Description	Qty Required
100	574853-12	BEARING	1
101	574853-05	BEARING	1
114	90573272	FLAT WASHER	4
117	90565052-01	FLAT SPRING	1
118	90570092	LOCK OFF SPRING	1
119	90562892-02	TRIGGER	1
120	90562893-02	LOCK BUTTON	1
121	770235	CORD PROTECTOR	1
122	90603745	HEX HEAD BOLT	1
123	330019-13	SCREW,PLASTITE	5
124	90578644	CONCRETE WEIGHT	1
125	90606208	HEAT SHRINK SLEEVE	2
127	90603460	LABEL	1
128	90601744	LABEL	1
129	90629074	NAME PLATE	1
130	90603462	LABEL	1
131	90629087	LABEL	1
133	90603461	WARNING LABEL	1
134	90508749	DANGER LABEL	1
135	90512672	DANGER LABEL	1
136	605111-00	WASHER	4
137	90638541	SWITCH BOX ASSY	1
140	90565532-02	BRUSH	2