


EXPLODED VIEW



REPLACEMENT PARTS LIST

Ref. No.	Part No.	Part Name & Descriptions	Per Set	Remarks
1	EY570B3078	Housing AB set	1	
2	EY570B6807	Fastening screw	1	
3	EY991B	Keyless drill chuck	1	available as an optional accessory
4	EY55149067	Tapping screw	2	
5	EY570B0297	Clutch mounting plate	1	
6	EY561H3228	Clutch handle	1	
7	EY570B0577	Clutch plate	1	
8	EY570B0168	Spring for clutch	1	
9	EY6280B0887	Thrust plate	2	
10	EY560B6967	Ball bearing	12	
11	EY570B1458	Gear box	1	
12	EY560B1517	Change-gear lever	1	
13	EY560B1547	Change-gear coupler	1	
14	EY560B0177	Spring A	2	
15	EY561H3238	Change-gear handle	1	
16	EY560B0187	Spring B	1	
17	EY570B1007	DC Motor	1	
18	EY551H3248	Forward/Reverse selector handle	1	
19	EY570Y2008	Switch	1	
20	EY531B6197	Screw for switch	2	
21	EY561B6117	Tapping screw A for housing	10	
22	EY561S9037	Tapping screw B for housing	1	
23	EY505B0287	Hand strap ring	1	
24	EY506B0277	Hand strap	1	
25	EY570B3098	Housing A for charger	1	
26	EY570B3028	Housing B for charger	1	
27	EY570B2127	Module	1	
28	EY570B2238	Power transformer	1	
29	EY570B2058	Power cord	1	
30	EY570B7658	Battery charger assembly	1	available as an optional accessory
31	EY570B7928	Double-ended #2 phillips bit	1	
32	EY570B0347	Lock release rod	1	
33	EY970B	Battery pack	1	available as an optional accessory