




**FinishPro® 33Mg**

## Finish Nailer



**Parts Reference Guide**  
**Guía de referencia**  
**de piezas**  
**Pièces Guide**  
**de référence**

Schematic Drawings Inside  
Plano esquemático en el interior  
Schéma intérieur

**Repair Kit**  
YK0787

# SENCO®

**Senco Brands, Inc.**  
4270 Ivy Pointe Blvd.  
Cincinnati, OH 45245  
1-800-543-4596  
[www.senco.com](http://www.senco.com)

**NFG06F • Revised March 18, 2014 (Replaces 5/14/11)**

Questions? Comments? call SENCO's toll-free Action-Line: 1-800-543-4596  
(North and South America Only) or email: [toolprof@senco.com](mailto:toolprof@senco.com)




¿Tiene preguntas? ¿Comentarios? Llame a la línea gratuita de acción de Senco: 1-800-543-4596  
(sólo para América del Norte y del Sur) o envíe un correo electrónico: [toolprof@senco.com](mailto:toolprof@senco.com)

Des questions? Des commentaires? Communiquez avec le service d'assistance sans frais de Senco : 1-800-543-4596  
(Amérique du Nord et Amérique du Sud seulement) ou envoyer un courriel: [toolprof@senco.com](mailto:toolprof@senco.com)

Tool #


6F0001N (U.S.)  
6F2001N (EU)

\* Does Not Include O-rings  
\* No incluye sellos de gomas  
\* Joints exclus







# Finish Nailer

# FinishPro® 33Mg



## Available Plugs (Not Included with Tool)

 <p>1/4" Body</p>	PC0480 ✓
Ind. Interchange 3/8" NPT	
 <p>3/8" Body</p>	PC0485
Ind. Interchange 3/8" NPT	
 <p>1/4" Body</p>	PC0469 ✓
Tru-Flate 3/8" NPT	
 <p>3/8" Body</p>	PC0475
Tru-Flate 3/8" NPT	

✓ **Recommended Plugs**  
Plugs shown smaller than actual size

## REPLACEMENT PARTS LIST • LISTA DE PARTES DE REPUESTO • LISTE DE PIÈCES DE RECHANGE

PART NO.	DESCRIPTION	DESCRIPCIÓN	DÉSIGNATION
AC0478	PLUNGER	VÁLVULA	VALVE
AC0479	SEAL	SELLO	JOINT
AC0480	CAP	TAPA	BOUCHON
AC0481	MAINBODY	CARCASA	CORPS
AC0482	BELT HOOK	GANCHO DE CINTURÓN	CROCHET DE CEINTURE
AC0483	SEAL	SELLO	JOINT
AC0484	CAP	TAPA	BOUCHON
BC0759	DEFLECTOR	DESVIADOR	DÉFLECTEUR
BC0760	VALVE	VÁLVULA	VALVE
BC0761	SEAL	SELLO	JOINT
BC0762	RETAINER	JUNTA TÓRICA	RETENUE
BC0763	COLLAR	CILINDRO	CYLINDRE
BC0764	RING	ANILLO	ANNEAU
BC0765	CYLINDER	CILINDRO	CYLINDRE
BC0766	SPACER	SEPARADOR	ENTRETOISE
BC0767	STOP	TOPE	ARRÊT
BC0768	GUIDE	GUÍA	GUIDE
CA0175	REMOTE VALVE ASY	ASAMBLE DE GATILLO VÁLVULA	GÂCHETTE/ VALVE
EA0237	PISTON DRIVER ASY	ASAMBLE DE PISYON Y	PISTON/COUTEAU
FC0752	COVER	CUBIERTA	COUVERCLE
FC0753	FRONT PLATE	PLACA	PLAQUE
FC0754	BACKPLATE	PLACA	PLAQUE
GC0902	RETAINER	JUNTA TÓRICA	RETENUE
GC1265	FEEDERSHOE	ALIMENTADOR	POUSSOIR
GC1266	MAGAZINE, UPPER	CARGADOR	MAGASIN
GC1267	RAIL	CARRIL	RAIL
GC1268	MAGAZINE, LOWER	CARGADOR	MAGASIN
GC1269	DETAINER	JUNTA TÓRICA	RETENUE
HA0246	TRIGGER ASY	ASAMBLE DE GATILLO	GÂCHETTED'ASSEMBLÉE
HC0502	PIN	PASADOR	GOUPILLE
HC0627	SAFETY ELEMENT	SEGURO	PALPEUR DE SÉCURITÉ
HC0628	SAFETY	SEGURO	PALPEUR DE SÉCURITÉ
HC0629	NO MAR PAD	AMORTIGUADOR	COUSSIN
KB6602	SPRING	RESORTE	RESSORT
KB6745	WASHER	ARANDELA	RONDELLE
KB6746	SCREW	TORNILLO	VIS
KB6747	SCREW	TORNILLO	VIS
KB6748	SPRING	RESORTE	RESSORT
KB6749	WASHER	ARANDELA	RONDELLE
KB6751	SCREW	TORNILLO	VIS
KB6752	SCREW	TORNILLO	VIS
KB6753	SCREW	TORNILLO	VIS
KB6754	SPRING	RESORTE	RESSORT
KB9828	SCREW	TORNILLO	VIS
KB9829	SCREW	TORNILLO	VIS
KB9837	NUT	TUERCA	ÉCROU
KB9910	WASHER	ARANDELA	RONDELLE
KB9911	WASHER	ARANDELA	RONDELLE
KB9912	PIN	PASADOR	GOUPILLE
LB0958	O-RING	SELLO	JOINT
LB0959	O-RING	SELLO	JOINT
LB1185	O-RING	SELLO	JOINT
LB1225	O-RING	SELLO	JOINT
LB1226	O-RING	SELLO	JOINT
LB1227	O-RING	SELLO	JOINT
LB1228	O-RING	SELLO	JOINT
LB1229	O-RING	SELLO	JOINT