



BOSCH

Cordless caulking gun

GCG 18V-20 | 3 601 JC4 010

Table of Content

Spare parts list.....	2
Illustration - Type.....	3

Spare parts list

Item	Part Number	Description	Illustration
8	1 601 11A 9R1	Nameplate	1
9	1 601 11C 2TP	Warning Plate	1
801	1 605 806 5RA	Housing Set	1
802	1 607 000 E6A	Set of screws	1
803	1 600 A01 C8C	Spring	1
804	1 607 000 E69	Trigger	1
805	1 607 000 E6U	Electronic Module	1
806	1 600 A01 2FH	Toothed rack	1
807	1 600 A01 55U	Rack	1
808	1 600 A02 R4C	Plunger	1
809	1 600 A01 55Y	Sachet plunger	1
810	1 600 A01 2FK	Pipe	1
811	1 600 A01 2F8	End cap	1
812	1 603 430 05Y	Screw	1
813	1 600 A01 2FA	Washer	1
814	1 600 A02 R4D	Screw and washer assembly	1

Illustration - Type - E

