



BOSCH

Diamond Drilling Machine

GDB 350 WE | 3 601 A89 931

Table of Content

Spare parts list.....	2
Illustration - Type.....	5

Diamond Drilling Machine | GDB 350 WE | 3 601 A89 931

Spare parts list

Item	Part Number	Description
8	1 601 11A 1G6	Nameplate
9	1 619 PB0 396	Manufacturer's nameplate
25	1 600 A00 73D	Armature With Fan 230V
30	1 604 220 53E	Field 230V
35	1 600 A01 AM1	Printed Circuit Board
40	1 600 A00 73F	Cooling Sheet
45	1 600 A00 742	Seal
50	1 600 325 008	Insulating Sleeve
60	1 600 591 05P	Air-Deflector Ring
65	1 600 A00 73G	Seal
70	1 600 A00 MZ7	Terminal Box
85	1 600 A00 73K	Carrying Handle
90	1 600 900 04R	groove ball bearing
95	1 600 900 04S	groove ball bearing
100	1 600 A00 73L	Shim
105	1 600 210 067	O-Ring
110	1 600 A00 4Y0	Rotary shaft lip seal
115	1 600 A00 73N	Hex Socket Head Cap Screw
120	1 600 A00 73P	Hex Socket Head Cap Screw
125	1 603 410 01D	Socket head cap screw
130	1 603 410 01E	Socket head cap screw
135	1 603 490 A0D	Countersunk-Head Screw
145	1 600 A01 9B5	Oval-Head Screw
150	1 600 A00 73S	Hex Nut
160	1 601 A01 3TB	Oval-Head Screw
170	1 600 150 021	Spring Washer
180	1 600 A00 73W	Plain Washer
190	1 600 A00 73X	Suppression Capacitor
200	1 600 A00 73Y	Mains Cable
205	1 600 A00 73Z	Cable Gland
215	1 600 A00 741	Mains switch
265	1 607 200 38P	Switch
400	1 605 806 59Y	Gear Housing
430	1 600 A00 743	Pinion Shaft
435	1 600 A00 744	Gear Shaft

Diamond Drilling Machine | GDB 350 WE | 3 601 A89 931

Spare parts list

Item	Part Number	Description
440	1 600 A00 77E	Hex Nut
445	1 600 300 10H	Bushing
450	1 600 A00 76R	Cylindrical Gear
455	1 600 A00 76S	Cylindrical Gear
460	1 600 A00 76T	Cylindrical Gear
465	1 600 A00 76U	Cylindrical Gear
480	1 600 A00 746	Protection Sleeve
490	1 600 A00 76V	Worm Shaft
495	1 600 900 04U	groove ball bearing
500	1 600 900 04V	groove ball bearing
505	1 600 900 04W	Needle-Roller Bearing
510	1 600 A00 76W	Nozzle Socket
515	1 600 A00 76X	Needle bearing
520	1 600 A00 76Y	Needle bearing
525	1 600 A00 76Z	Needle Axial Ball Bearin
530	1 600 A00 770	Thrust Needle Rim
535	1 600 A00 771	Thrust Bearing Disc
540	1 600 210 068	O-Ring
545	1 600 210 069	O-Ring
550	1 600 210 063	O-Ring
555	1 600 210 064	O-Ring
560	1 600 A00 772	Shaft Seal
565	1 600 A00 773	Shaft Seal
570	1 600 A00 774	Shaft Seal
605	1 600 A00 4YF	Seal Ring
610	1 600 A00 777	Helical compress. spring
615	1 600 A00 77A	Ball
625	1 600 A00 77B	Parallel Key
630	1 600 A00 77C	Parallel Key
635	1 600 A00 77D	Parallel Key
655	1 600 150 022	Spring retaining ring
660	1 600 150 023	Spring retaining ring
670	1 604 601 02P	Retaining ring
675	1 600 A00 79B	Cylindrical Gear
680	1 600 A00 77G	Hex Socket Head Cap Screw

Spare parts list

Item	Part Number	Description
685	1 600 A00 77H	Hex Socket Head Cap Screw
690	1 600 A00 73V	Locking Washer
805	1 605 108 2C1	Motor Housing
810	1 600 A00 77L	Intermediate Flange
820	1 605 500 2BL	Cover
840	1 600 A00 77N	Threaded joint
850	1 602 026 102	Clamp Handle
855	1 600 A00 77P	Brush Holder
875	1 600 A00 8WC	Hose
878	1 600 A00 77R	Sliding Clutch
880	1 607 014 17M	Carbon-Brush Set
890	1 605 820 23B	Bearing cover
891	1 600 A00 77S	Drilling Spindle
892	1 600 A00 5AY	Isolating Valve
893	1 600 A00 77U	water connection
895	1 600 A00 77X	Mains Cable
900	1 600 A00 780	Glide ring
915	1 600 210 06D	O-Ring

Illustration - Type - E

