



BOSCH

Circular hand saw

GKS 66 X | 3 601 F76 180

Table of Content

Spare parts list.....	2
Illustration - Type.....	5

Circular hand saw | GKS 66 X | 3 601 F76 180

Spare parts list

Item	Part Number	Description	Quantity
5	1 604 460 225	Power supply cord CN 2,65m 2 x 1,5mm H07 RN-F	1
6	2 600 703 017	Grommet Ø6,4-Ø7,2x76 MM	2
7	1 619 P06 313	Cable Clip	1
11	1 619 P06 286	Insulating Cap	1
12	2 610 917 620	Suppression Filter	2
13	1 619 P00 456	Ball Bearing 7x19x6 MM	1
14	1 619 P10 481	Ball Bearing	1
19	2 603 490 021	Torx Oval-Head Screw 4x12	2
22	2 610 935 251	Compression Spring	2
24	1 619 P09 797	Baffle	1
25	1 619 P10 789	Cap	1
26	1 619 P10 115	Set Of Handles	1
27	1 619 P06 227	Rubber Ring	1
28	1 619 P10 806	Connecting Cable	1
29	1 619 P10 807	Connecting Cable	1
30	1 619 P04 476	Sealing disk	1
31	1 619 P10 795	Shim plate	1
33	1 619 P06 225	Cap	1
35	1 619 P00 291	Ball BLUE	1
36	1 619 P10 145	Cap	1
37	2 603 201 020	Bearing bolt	2
38	1 619 P10 138	Guide Bracket	1
39	1 619 P10 139	Contact strap	1
40	1 619 P06 319	Lock Nut	1
47	1 619 P06 310	Needle bearing	1
48	1 619 P10 132	Ball Bearing	1
50	1 619 P10 784	Washer	1
51	1 619 P10 785	Locking Washer	1
52	1 619 P10 786	Clamp Screw	1
54	2 916 650 014	Spring retaining ring DIN 471 25x1,2	2
56	1 619 P10 141	Rod	1
57	F 000 640 007	O-Ring	1
58	1 619 P10 118	Safety Guard	1
59	1 619 P10 142	Connection Lever	1

Circular hand saw | GKS 66 X | 3 601 F76 180

Spare parts list

Item	Part Number	Description
60	1 619 P10 133	Extension Spring
61	1 619 P06 236	Bumper BLACK
62	1 604 611 031	Compression Spring
63	1 619 P10 140	Rubber Pad
64	1 619 P10 144	Support bracket
65	1 619 P06 325	Knurled Bolt
66	1 619 P10 116	Protective Guard
67	1 619 P10 608	Slotted Spring Pin
68	1 619 P10 117	Protective Cover
70	2 610 924 685	Adjusting Screw
72	2 604 610 028	Compression Spring
75	1 619 P10 801	Guide Cover
76	1 619 P06 244	Wing Nut
77	2 916 011 014	Plain Washer DIN 125-A 6,4-ST
78	1 619 P06 211	Round-Head Bolt
79	1 619 P10 788	Switch Button
80	1 619 P10 037	Lever
81	1 619 P07 060	Connecting Cable
82	1 619 P09 798	Nut
83	1 619 X01 792	Spring BLACK
84	1 619 P17 212	Cover
85	1 619 P01 618	Wing Screw BLACK
86	1 619 P10 787	Trigger
87	2 603 490 022	Screw 4x16
88	2 610 925 864	Screw
93	1 619 P06 246	Screw
94	1 619 P01 678	Screw
95	1 603 435 068	Thread-forming tap. Screw DIN 7500, M4x10, SR10.2
651	2 610 364 015	Hexagon Socket Screw Key 5 MM
653	1 619 X01 612	Mitre Fence
801	1 619 P10 061	Motor Housing BLUE
803	1 619 P11 497	Armature set
810	1 619 P10 063	Carbon-Brush Set
832	1 619 P10 805	LED lamp

Spare parts list

Item	Part Number	Description
843	1 619 P11 494	Gear Shaft
853	1 619 P11 495	Bearing Flange
869	1 619 P11 493	Base Plate

Illustration - Type - E

