



BOSCH

Router

GMR 550 | 3 601 FA0 080

Table of Content

Spare parts list.....	2
Illustration - Type.....	3

Spare parts list

Item	Part Number	Description	
3/5	2 609 100 246	Fan	
4	1 607 200 289	Switch	
5	1 604 460 309	Power supply cord	
6	2 600 703 017	Grommet	Ø6,4-Ø7,2x76 MM
7	2 601 035 001	Cable Clip	
12	2 609 120 600	Suppression Filter	
13	2 609 110 435	groove ball bearing	
14	2 609 110 436	groove ball bearing	
16	2 609 110 217	Brush Holder	
17	2 609 100 203	Brush-Cover	
18	2 609 110 294	Spring Washer	
19	2 910 611 093	Tapping Screw	
20	2 609 101 190	Housing Cover	BLUE
21	2 609 101 192	Chassis	BLUE
23	2 910 611 020	Tapping Screw	DIN 7981-ST3,9x19-C-H
24	2 916 650 006	Retaining clip	DIN 471-15x1-FSt
25	2 609 111 660	Contact Strip	
26	2 609 120 597	Terminal Block	
27	2 609 135 344	Label	
30	2 609 110 208	contour sleeve	
31	2 609 110 209	Nut	
63	2 609 120 256	Connecting Cable	
650	2 609 111 921	Guide	
651	2 609 111 740	Jaw Wrench	SW 10
652	2 609 110 254	Jaw Wrench	SW 17
653	2 610 008 113	Edge Guide	
654	2 609 199 030	Guide	
655	2 609 199 836	Base	
655/2	2 609 101 194	Base Plate	
655/9	2 609 110 619	Screw	
801	2 609 199 880	Housing	BLUE
802	1 607 000 C58	Stator	230V
803	2 609 199 884	Armature set	230V
810	2 609 120 149	Carbon-Brush Set	

Illustration - Type - E

