



BOSCH

Laser Level

GRL2000-40HV | 3 601 K61 S10

Table of Content

Spare parts list.....	2
Illustration - Type.....	4

Laser Level | GRL2000-40HV | 3 601 K61 S10

Spare parts list

Item	Part Number	Description	Illustration
1/1/1	1 609 922 1BA	Motor Housing	1
1/1/10	2 610 A13 399	Limit Switch	1
1/1/1/14	2 610 A13 249	Motor-gearbox assembly	1
1/1/1/14/7	2 610 A12 302	Motor Plate	1
1/1/1/18	2 610 A12 283	Extension Spring	1
1/1/1/19	2 610 A13 065	Extension Spring	1
1/1/2	1 609 922 1EM	Assembly	1
1/1/3	2 610 A13 397	Limit Switch	1
1/1/4	2 610 A12 269	Special Washer	1
1/1/5	2 610 A12 272	Hex Socket Head Cap Screw	1
1/1/6	2 610 A12 284	Hex Socket Head Cap Screw	1
1/1/7	2 610 A12 359	Flexible Pcb	1
1/1/8	2 610 A12 301	Tapping Screw	1
1/2	1 609 922 1JG	prism support	1
1/4	1 609 922 1EP	Assembly	1
1/5	2 610 A15 789	ball sleeve	1
1/7	2 610 A14 200	Wave spring	1
2	1 609 922 1F7	Housing	1
3	2 610 A12 957	Housing	1
4	2 610 A12 464	Handle	1
5	2 610 A12 309	Handle	1
6	2 610 A12 327	Battery box assembly	1
7	1 609 922 1EX	Cage	1
8	2 610 A12 310	Threaded Bolt	1
9	2 610 A12 348	Hex Socket Head Cap Screw	1
10	2 610 A12 459	Hex Socket Head Cap Screw	1
11	2 610 A12 460	Hex Socket Head Cap Screw	1
12	1 601 11A 5X1	Nameplate	1
14	1 600 A01 9FR	Keyboard	1
15	2 610 A06 622	Window	1
16	2 610 A13 364	Rubber Gasket	1
17	2 610 A13 365	Rubber Gasket	1
19	2 610 A12 270	Set screw	1
802	1 609 922 1KR	Laser detector	2
802/25	2 609 101 735	Battery Cover	2

Spare parts list

Item	Part Number	Description	Illustration
805	1 600 A00 FD1	Clamp Bracket	2
815	1 609 922 1KY	Remote Control	2
818	1 609 922 1EY	Mounting Bracket	2

Illustration - Type - E

3 601 K61 S10
 Issue
 Stand 20-02-18 **Fig./Abb. 1**





Illustration - Type - E

3 601 K61 S10
Issue
Stand) 20-02-14 **Fig./Abb. 2**



Modifications reserved
Änderungen vorbehalten
Modifications réservées
Salvo modificaciones