



BOSCH

Laser Level

GRL 250 HV | 3 601 K61 611

Table of Content

Spare parts list.....	2
Illustration - Type.....	4

Spare parts list


Item	Part Number	Description	Illustration
1/1/1	1 605 108 2MP	Motor Housing	1
1/1/10	2 610 A13 399	Limit Switch	1
1/1/2	1 600 A01 NX6	Leveling element	1
1/1/3	2 610 A13 397	Limit Switch	1
1/1/4	2 610 A12 269	Special Washer	1
1/1/5	2 610 A12 272	Hex Socket Head Cap Screw	1
1/1/6	2 610 A12 284	Hex Socket Head Cap Screw	1
1/1/7	2 610 A12 359	Flexible Pcb	1
1/1/8	2 610 A12 301	Tapping Screw	1
1/2	2 610 A12 298	lens mount	1
1/3	2 610 A12 321	Rotating Beacon	1
1/4	2 610 A12 340	Housing Assembly	1
1/5	2 610 A12 224	ball sleeve	1
1/6	2 610 A12 461	Hex Socket Head Cap Screw	1
2	2 610 A14 450	Housing	1
3	2 610 A12 957	Housing	1
4	2 610 A12 464	Handle	1
5	2 610 A12 309	Handle	1
6	2 610 A12 327	Battery box assembly	1
7	2 610 A12 311	Cage	1
8	2 610 A12 310	Threaded Bolt	1
9	2 610 A12 348	Hex Socket Head Cap Screw	1
10	2 610 A12 459	Hex Socket Head Cap Screw	1
11	2 610 A12 460	Hex Socket Head Cap Screw	1
12	2 610 A13 441	Nameplate	1
14	2 610 A13 404	Keyboard	1
15	2 610 A12 302	Motor Plate	1
17	2 610 A12 275	Hex Socket Head Cap Screw	1
18	2 610 A12 283	Extension Spring	1
19	2 610 A13 065	Extension Spring	1
21	2 610 A13 249	Motor-gearbox assembly	1
680	1 617 S00 W3M	Remote Control	1
801/1/1	2 610 A12 237	Motor Housing	1
801/4	1 600 A01 R7U	Assembly	1
802	1 600 A01 R89	Housing	1

Spare parts list

Item	Part Number	Description	Illustration
821	1 600 A01 R7V	Motor-gearbox assembly	1

Illustration - Type - E

3 601 K61 510
Issue | 22-03-17
Stand | **Fig./Abb. 1**



Modifications reserved
Änderungen vorbehalten
Modifications réservées
Salvo modificaciones