



BOSCH

Laser Level

GRL 250 HV | 3 601 K61 612

Table of Content

Spare parts list.....	2
Illustration - Type.....	3

Spare parts list

Item	Part Number	Description	Illustration
1/3	2 610 A12 321	Rotating Beacon	1
1/4	2 610 A12 340	Housing Assembly	1
1/6	2 610 A12 461	Hex Socket Head Cap Screw	1
1/7	2 610 A12 284	Hex Socket Head Cap Screw	1
2	2 610 A12 342	Housing	1
3	2 610 A12 957	Housing	1
4	2 610 A12 464	Handle	1
5	2 610 A12 309	Handle	1
6	2 610 A12 327	Battery box assembly	1
7	2 610 A12 311	Cage	1
8	2 610 A12 310	Threaded Bolt	1
9	2 610 A12 348	Hex Socket Head Cap Screw	1
10	2 610 A12 459	Hex Socket Head Cap Screw	1
11	2 610 A12 460	Hex Socket Head Cap Screw	1
14	2 610 A13 403	Keyboard	1
680	1 617 S00 W3M	Remote Control	1
801	2 610 A15 780	Assembly	1

Illustration - Type - E

3 601 K61 612
Issue | 22-03-17
Stand | **Fig./Abb. 1**

