

SPARE PARTS LIST

MODEL NO. GS5000

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	424549-0	INSULATION COVER	1	
002	922422-3	HEX. SOCKET HEAD BOLT M8X16	2	
003	165714-9	WHEEL COVER 125	1	
004	346656-8	TIGHT BAND	1	
005	266046-8	TAPPING SCREW 5X50	4	
006	256180-2	PIN 3	1	
007	252007-4	HEX. NUT W1/2-21	1	
008	224019-7	OUTER FLANGE 50	1	
009	224457-3	INNER FLANGE 50	1	
010	961060-6	RETAINING RING S-20	1	
011	285824-7	BEARING RETAINER 31-48	1	
012	211306-3	BALL BEARING 6204LLB	1	
013	318961-3	GEAR HOUSING	1	
014	268161-4	PIN 5	1	
015	326251-0	SPINDLE B	1	
016	211256-2	BALL BEARING 6203LLB	1	
017	257253-4	RING 17	1	
018	227766-9	HELICAL GEAR 47	1	
019	213656-2	O RING 53	1	
020	318962-1	GEAR HOUSING COVER	1	
021	213487-9	O RING 31	1	
022	211129-9	BALL BEARING 6201DDW	1	
023	962151-6	RETAINING RING R-32	1	
024	240143-8	FAN 80	1	
025	517889-4	ARMATURE ASS'Y 240V INC. 24,26,27	1	
026	681657-2	INSULATION WASHER	1	
027	210059-1	BALL BEARING 6000DDW	1	
028	421490-8	RUBBER RING 26	1	
029	266038-7	TAPPING SCREW 5X70	2	
030	451480-7	BAFFLE PLATE	1	
031	523424-8	FIELD ASSY 240V	1	
032	140222-1	MOTOR HOUSING COMPLETE	1	
033	643700-5	BRUSH HOLDER CAP 7-18	2	
034	191957-7	A.C. CARBON BRUSH CB-204	1	
035	814H98-7	GS5000 NAME PLATE	1	
036	188848-1	HANDLE SET INC. 44	1	
039	650101-0	SWITCH TG08-1100-011	1	
040	266192-7	TAPPING SCREW 4X14	1	
041	687169-3	STRAIN RELIEF	1	
042	682540-6	CORD GUARD 9.3-90	1	
043	692527-0	POWER SUPPLY CORD 1.0-2-2.5	1	
044	188848-1	HANDLE SET INC. 36	1	
045	265999-8	TAPPING SCREW 4X25	4	
A01	410047-0	WRENCH HOLDER 5.6	1	
A02	781029-2	WRENCH 21	1	
A03	783204-6	HEX. WRENCH 6	1	

SERVICE DRAWING

MODEL NO. GS5000

