



BOSCH

Percussion Drill

GSB 600 RE | 3 601 B17 181

Table of Content

Spare parts list.....	2
Illustration - Type.....	3

Spare parts list

Item	Part Number	Description
1	2 605 105 105	Housing Section
2	2 604 220 718	Field 230V
4	2 607 200 623	Switch
5	2 604 460 245	Power supply cord CN 220V 2,65m 2 x 0,75mm H05 VV-F
6	2 600 707 059	Grommet Ø6,9 MM
13	2 609 110 153	Ball Bearing 8x22x7
14	2 609 110 491	Ball Bearing
16	2 609 120 317	Brush Plate
21	2 600 409 021	Shrinkable Tube
25	2 609 100 580	Lever
32	1 903 230 010	Ball DIN 5401-5,5MM-III-ST
34	2 609 199 073	Bearing Bracket
36	2 609 110 441	Drilling Spindle
37	2 606 320 092	Conversion Gear
38	2 609 110 442	Sintered-Metal Bushing
41	2 604 616 006	Compression Spring
654	2 602 025 094	Auxiliary Handle
803	2 609 120 232	Armature 220-240V
810	2 610 391 290	Carbon-Brush Set
831	2 609 160 127	Change-Over Switch
836	2 609 160 123	Drilling Spindle
839	1 608 571 080	Key Chuck Ø1,5-13 MM
839	2 608 571 076	Chuck
839/7	2 607 950 007	Chuck Wrench SG2
892	2 603 490 022	Screw 4x16
893	2 601 035 001	Cable Clip
895	3 605 430 003	Grease Tube Albida

Illustration - Type - E

