



BOSCH

Cordless Drill Driver

GSR 18-2-LI | 3 601 JA4 380

Table of Content

Spare parts list.....	2
Illustration - Type.....	3

Spare parts list

Item	Part Number	Description
1	2 609 100 810	Housing BLUE
4	1 607 233 299	Electronics Module
5	2 609 100 863	Lever
9	2 609 132 505	Manufacturer's nameplate GSR 18-2-LI
25	2 609 110 799	Keyless Chuck 10 MM
32	2 609 199 251	Slide Switch
38	2 609 110 801	Tab Washer
40	2 609 110 802	Screw
45	2 609 199 255	Gear Box
46	1 609 280 477	Compression Spring
91	1 607 A35 0JR	Battery Pack GBA 18V 1.5Ah
100	2 609 110 956	Clip
101	2 609 110 201	Torx Flat-Head Screw 3x16
103	2 609 110 835	Nut
105	2 609 110 834	Screw
107	2 609 110 635	Pan head screw M 6x30
109	2 609 110 342	Screwdriver Blade
653	2 607 225 439	Fast Charger CN 220/10,8-18V, 1h
802	2 609 199 273	DC motor 18V
804	1 609 280 478	Contact retainer
808	2 609 132 479	Nameplate

Illustration - Type - E

3 601 JA4 300
 Stand } 09-05
 Issue } 10-01-29

Fig. /Abb. 1

Anzugsmomente
 Torque values
 Couple de serrage
 Pares de apriete
 Pos 40 = 0,5- 0,8 Nm
 101 = 0,8- 1,0 Nm
 105 = 1,7- 2,0 Nm
 107 = 4,0 5,0 Nm

