



BOSCH

Cordless Drill Driver

GSR 185-LI | 3 601 JK3 081

Table of Content

Spare parts list.....	2
Illustration - Type.....	3

Spare parts list

Item	Part Number	Description	
1	1 605 806 62H	Housing	
3	1 619 P15 696	Stator	
5	1 600 A01 Z04	Changeover Lever	
6	2 607 202 513	Electronics Module	
9	1 601 11C 4W3	Manufacturer's nameplate	
25	1 600 A02 7W8	Keyless Chuck	
32	1 600 A01 2MM	Switchover Unit	
42	1 601 11C 4W5	Sticker	
45	1 600 A02 E8E	Gear Box	
46	1 609 280 477	Compression Spring	
91	1 607 A35 0M0	Battery Pack	GBA 18V 4.0Ah
91	1 607 A35 0MN	Battery Pack	GBA 18V 2.0Ah
101	2 609 110 201	Torx Flat-Head Screw	3x16
107	2 603 421 229	Countersunk-Head Screw LEFTHAND THREADS	M6x23
652	1 600 A02 7W3	Clip	
653	2 607 226 253	Fast Charger	GB GAL 18V-40
653	2 607 226 297	Fast Charger 2A	CN GAL 18V-20 220V 12V-18V
802	1 607 000 EC2	Rotor	
808	1 601 11A 99T	Nameplate	

Illustration - Type - E

