



**BOSCH**

# Delta Sander

GSS 180 A-C | 0 601 29A 094

---

## Table of Content

Spare parts list.....	2
Illustration - Type.....	3

## Spare parts list

Item	Part Number	Description
1	2 605 105 023	Housing Section BLUE
2	2 604 220 673	Field 230-240V
3	2 604 011 276	Armature 230-240V
4	2 607 200 526	Switch
5	2 604 460 245	Power supply cord CN 220V 2,65m 2 x 0,75mm H05 VV-F
6	2 609 002 019	Grommet
7	2 603 490 017	Torx Oval-Head Screw 3x10
9	2 601 116 043	Manufacturer's nameplate
10	2 604 337 088	Brush Plate
13	2 600 905 078	groove ball bearing
15	2 606 610 113	Fan
19	2 603 490 022	Screw 4x16
21	2 608 000 238	Sander Plate
24	2 600 290 039	Seal Ring
25	2 604 448 247	Connecting Cable L=160 MM BLUE
26	3 604 440 527	Connecting Cable L=63 MM WHITE
28	2 609 000 549	Rubber Buffer
50	2 605 411 121	Dust container 1 PIECE
803	2 604 010 980	Armature 230-240V
808	2 601 116 624	Nameplate
811	2 604 321 925	Carbon-Brush Set
819	2 600 905 045	groove ball bearing 12x28x8
821	1 601 110 G87	Reference Plate

Illustration - Type - E

