



BOSCH

Jig Saw

GST 150 BCE | 3 601 E13 081

Table of Content

Spare parts list.....	2
Illustration - Type.....	4

Spare parts list

Item	Part Number	Description
1	2 605 105 128	Housing Section BLUE
2	2 604 220 584	Field 230-240V
3/9	2 606 610 089	Fan
4	2 607 200 669	Switch
5	2 604 460 273	Power supply cord H05 RN-F China 4,15m 2x1mm
6	2 600 703 017	Grommet Ø6,4-Ø7,2x76 MM
7	2 601 035 004	Cable Clip
14	2 600 905 112	groove ball bearing 9x24x7
16	2 605 807 109	Brush Plate
17	1 603 100 036	Rubber Buffer
18	2 916 660 008	Spring retaining ring DIN 472-24x1,2 MM
19	2 603 490 022	Screw 4x16
26	2 600 100 040	Shim
27	2 916 080 908	Locking Washer 5 DIN 6799
31	2 600 101 119	Shim
32	2 600 913 040	Needle-Roller Assembly
33	2 606 320 099	Eccentric Cog Wheel
35	2 601 923 015	Fork Lever
36	2 601 098 117	Counterweight
37	2 600 101 047	Shim 0,3 MM
38	2 916 080 909	Locking Washer DIN 6799-6-FST
38	2 916 640 905	Spring retaining ring 8x0,8 N31A MR7
41	2 600 917 900	Needle bearing
51	2 603 105 131	Bearing bolt
53	2 603 124 156	Control Shaft
56	2 602 026 158	Rotary Knob BLACK
61	2 604 610 140	Compression Spring
64	2 601 322 035	Straight Pin
80/2	2 601 099 198	Work Board
80/4	1 613 435 023	Thread-forming tap. Screw
84	2 610 364 015	Hexagon Socket Screw Key 5 MM
85	2 601 030 022	Profile Beading
87	2 605 500 203	Baffle BLACK
88	2 600 040 004	fixing plate

Spare parts list

Item	Part Number	Description
90	2 910 141 201	Hex Socket Head Cap Screw DIN 912-M6x20-8.8
95	2 603 101 065	Protecting Cover
97	2 604 448 343	Earth Conductor
98	2 604 448 335	Connecting Cable
99	2 603 410 051	Thread-forming tap. Screw
105	2 604 690 056	Torsion Spring
113	1 607 233 560	Speed governor 220-240V
115	2 604 448 336	Connecting Cable
117	2 603 490 023	Torx Oval-Head Screw 4x20
118	1 600 A02 B9X	Sponge
119	1 600 A02 D4B	Sponge
654	2 601 099 183	Pad
655	2 601 016 093	Splintering Protector
656	2 605 730 055	Suction Nozzle
657	2 605 510 293	Covering hood
801	2 602 026 908	Cap-Handle BLACK
803	2 604 011 394	Armature 230-240V
810	2 604 321 941	Carbon-Brush Set
823	2 605 806 881	Gear Housing
845	2 601 321 908	Roller Lever
854	2 602 026 909	Rotary Knob BLACK
860	2 605 808 934	Gear Cover
866	1 600 A00 HG2	Lifting Rod
880	2 601 016 905	Base Plate

Illustration - Type - E

