



BOSCH

Cordless Jigsaw

GST 18V-50 | 3 601 EB3 010

Table of Content

Spare parts list.....	2
Illustration - Type.....	4

Spare parts list


Item	Part Number	Description	Illustration
1	1 619 P16 208	Housing Section	1
2	1 619 P16 473	Stator	1
3	1 619 P16 471	Rotor	1
9	1 619 P17 254	Manufacturer's nameplate	1
10	1 619 P16 218	Electronics Module	1
19	2 609 110 201	Torx Flat-Head Screw 3x16	1
20	1 619 P17 545	Warning Label	1
22	1 619 P07 152	Torsion Spring	1
23	1 619 P07 128	Protecting Cover	1
24	1 619 P07 151	Lever Switch	1
27	1 619 P16 223	Eccentric Cog Wheel	1
28	1 619 P16 219	Adjusting Slide	1
29	2 600 914 022	Needle bearing	1
30	1 619 P07 576	Shim	1
31	2 600 913 040	Needle-Roller Assembly	1
32	2 600 101 077	Shim 0,5 MM	1
33	1 619 P07 137	Fork Lever	1
34	2 600 590 006	Ratchet Cap	1
36	2 600 100 588	Shim 0,5 MM	1
37	1 619 P07 133	Counterweight	1
39	2 916 640 905	Spring retaining ring 8x0,8 N31A MR7	1
40	1 619 P07 147	Lifting Rod	1
41	1 619 P08 903	Plain bearing	1
42	1 619 X08 384	Coiled Spring	1
43	1 619 P07 139	Needle Roller	1
44	1 619 P07 143	Bearing bolt	1
45	1 619 P16 715	Base Plate	1
46	1 619 P07 138	Bearing bolt	1
47	2 601 030 022	Profile Beading	1
48	1 619 P07 163	fixing plate	1
49	2 916 640 001	Spring retaining ring DIN 471-4x0,4-FSt	1
51	1 609 280 477	Compression Spring	1
52	1 613 435 023	Thread-forming tap. Screw	1
53	1 619 P10 589	Key Holder	1
54	1 619 P16 713	Work Board	1

Spare parts list

Item	Part Number	Description	Illustration
55	1 619 P17 546	Warning Label	1
57	1 619 P02 848	Torx Oval-Head Screw 4x12	1
58	1 619 P07 129	Roller Lever	1
58	1 619 P13 426	Roller Lever	1
59	1 619 P07 159	Bearing bolt	1
63	1 619 P07 156	Control Shaft	1
65	1 619 X04 887	Hex Socket Head Cap Screw	1
67	1 619 P07 158	Switch Slide	1
71	1 605 500 2CJ	Cover	1
72	2 603 435 015	Cross Recessed-Head Screw DIN 7981-ST3,5x9,5-F	1
210	1 619 P17 245	Sticker	1
651	1 619 P16 710	Pad	1
652	1 619 P14 506	Offset Screwdriver	1
653	2 601 016 093	Splintering Protector	1
656	1 619 P07 166	Covering hood	1
808	1 619 P17 253	Nameplate	1
826	1 619 P08 888	Bearing Bracket	1
845	1 619 P16 712	Base Plate	1
862	1 619 P08 890	Change-Over Switch	1
873	1 619 P17 472	Suction Socket	1
657	1 607 A35 0M0	Battery Pack GBA 18V 4.0Ah	2
669	2 607 226 257	Fast Charger USA GAL 18V-40 120V/ 4A/ 10.8-18V	2
669	2 607 226 287	Charger US GAL 18V-20 120V / 2A	2
895	3 605 430 003	Grease Tube Albida	2

Illustration - Type - E

3 601 EB3 010
Issue | 22-05-12
Stand | Fig./Abb. 2



Modifications reserved
Änderungen vorbehalten
Modifications réservées
Salvo modificaciones