



BOSCH

Cordless Screw Driver

GTB 18V-45 | 3 601 JK7 010

Table of Content

Spare parts list.....	2
Illustration - Type.....	3

Cordless Screw Driver | GTB 18V-45 | 3 601 JK7 010

Spare parts list

Item	Part Number	Description	Illustration
1	1 600 A02 4AZ	Housing	1
2	1 619 P16 440	Stator	1
4	1 607 233 5N0	Speed governor	1
5	2 607 202 902	Switch	1
6	1 600 A01 D6X	Lever Switch	1
7	2 600 590 006	Ratchet Cap	1
8	1 600 A02 8VU	Warning Label	1
9	1 601 11C 4G1	Manufacturer's nameplate	1
11	1 601 11C 41N	Sticker	1
12	1 600 A02 61R	Separator	1
45/20	1 600 A01 A4D	Depth-Gauge	1
45/30	1 618 597 13F	Toolholder	1
46	1 609 280 477	Compression Spring	1
48	2 609 110 838	Clip	1
91	1 607 A35 0AP	Battery Pack USA GBA18V40 18V 4.0Ah ProCore SCM	1
91	1 607 A35 0BM	Battery Pack BAT612 18V 2.0Ah Li SCM	1
101	2 609 110 201	Torx Flat-Head Screw 3x16	1
102	2 603 490 022	Screw 4x16	1
181	1 601 11C 2X6	Reference Plate	1
650/1	2 609 111 584	Clip	1
650/2	2 609 110 834	Screw	1
653	2 607 226 257	Fast Charger USA GAL 18V-40 120V/ 4A/ 10.8-18V	1
653	2 607 226 287	Charger US GAL 18V-20 120V / 2A	1
803	1 607 000 E6G	Rotor	1
808	1 601 11A 8M2	Nameplate	1
810	1 607 000 E6H	Friction Washer	1
845	1 607 000 E6J	Gear Unit	1
845/10	1 607 000 E6K	Gear Housing	1
850	1 607 000 E9S	Planet Gear	1

Illustration - Type - E

