


ENGINE PARTS - IDC 200-1




Item	Part No.	Description	Item	Part No.	Description
1	610311	Spark Plug	24	610309	Seal
2	683374	Cylinder Assembly	25	610308	Outer Bearing
3	612164	Cylinder Gasket	26	682040	Snap Ring Assembly
4	683375	Piston and Rod Assembly	27	683387	Engine Mount Assembly
5	683376	Muffler Assembly	28	611063	Ground Tab
6	612165	Exhaust Gasket	29	683388	Flywheel
7	683377	Muffler Mounting Bolt Assembly	30	683389	Flywheel Nut Assembly
8	683378	Carburetor/Air Filter Cover	31	683390	Module Assembly
9	612111	Air Cleaner Filter	32	683391	Wire Lead Assembly
10	683379	Mounting Bolt Assembly	*33	683392	Crankcase Service Assembly (items 21-26)
11	612112	Air Cleaner Base	*34	683393	Engine Gasket Kit
12	683380	Choke Lever Assembly	*35	683394	O.E.M. Carburetor Repair Kit
13	683381	Carburetor Assembly	*36	153309	Gasket-Diaphragm Repair Kit
14	612113	Carburetor Gasket (10 pack)	*37	682507	Piston Ring
15	147621	Reed Plate Assembly	*38	610676	Flywheel Key (10 pack)
16	147622	Reed Assembly			
17	612114	Reed Plate Gasket (10 pack)			
18	683384	Cover Mounting Bolt Assembly			
19	683385	Rear Cover Assembly			
20	612115	Rear Cover Gasket (10 pack)			
21	180002	Power Shaft Assembly			
22	612116	Crankcase			
23	682041	Inner Bearing Assembly			

* not shown

The above part numbers are for serial numbers 909018527 thru 009120700.

BLOWER PARTS - IDC 200-1



Item	Part No.	Description
39	147730	Starter Cover
40	610300	Pull Handle
41	611061	Rope Guide
42	612118	Recoil Spring
43	612119	Rope
44	612120	Starter Pulley
45	612121	Starter Cam
46	683396	Pulley Mounting Screw Assembly
47	612122	Starter Cam Spring
48	147717	Starter Cover Assembly (includes items 38-47)
49	180000	Fuel Cap Assembly (items 49-51)
50	180023	Fuel Tank
51	683398	Fuel Line Assembly
53	682542	Switch Assembly
54	683400	Trigger Assembly
55	153516	Handle Cover Assembly
56	153517	Engine Cover Assembly
57	145813	Blower Housing Engine Side
58	683403	Throttle Wire and Housing Assembly
59	612125	Heat Shield

Item	Part No.	Description
60	612126	Air Seal
61	683404	Mounting Bolt Assembly
62	683405	Impeller Assembly
63	145814	Blower Housing-Blower Side
64	683406	Mounting Bolt Assembly
65	153518	Extension Upper
66	145815	Fan Nozzle
67	683425	Mounting Pad Set
68	683427	Spacer Set
69	153536	Extension Lower
70	683424	Clamp Assembly
71	683395	Starter Cover Mounting Screws

Optional Accessories

- * 682875 Shoulder Strap
- * 153407 IDC or Ryan 2-Cycle Oil
- * 683823 Spark Arrestor Kit
- * 147300 Gutter Clean Out Kit
- * not shown