



Parts List for LSW60C Type 1

Item Number	Part Number	Description	Qty Required
1	90631418	HOUSING ASSEMBLY	1
2	330019-03	SCREW,PLASTITE	11
3	90637061	LENS	1
4	632492-00	PIN	1
5	90631428	BUTTON	1
6	90623558	ACTUATOR SPRING	1
7	90631429	SWITCH ACTUATOR	1
8	90636534	TORSION SPRING	1
9	90633866	LATCH	1
10	330019-01	SCREW PLASTITE	6
11	90631424	INLET CAP	1
12	90560803	FLANGE NUT	1
13	90631426	FAN	1
14	90631422	HOUSING,STATOR	1
15	90631430	COLLAR	1
16	90631423	BLOWER TUBE	1
17	90637872	SCRAPER	1
18	90631421	MOTOR ASSEMBLY	1
28	90632461	HARNESS ASSY.	1
31	N496799	FOAM PAD	2
866	LBX1560	BATTERY	1
871	90642267	CHARGER	1
871	BDCAC60B	CHARGER	1