



Model LXLM03 Parts List

A = Standard Equipment

O= Circuit Diagram

Item#	Part#	Description	Q'ty	Unit
1	GM00001117	BATTERY HOLDER C2010239007	1	PC.
2	GM00001287	HOUSING R/L(G0180100105)	1	
3	GM00001269	SCREW 3X12PB(B0130120202)	5	
4	GM00001285	SWITCH HOLDER ASSY(G0180100103)	1	
5	GM00001286	MAIN CIRCUIT ASSY(G0180100104)	1	
6	GM00001266	MAGNET RING(B)(A2301005900)	1	
7	GM00001269	SCREW 3X12PB(B0130120202)	3	
8	GM00001273	LEFT ROTATOR (C0120801005)	1	
9	GM00001270	SPRING (B1214801020)	1	
10	GM00001279	SPRING LID (C1020801001)	1	
11	GM00001271	ROTATOR BRACKET L(C0120801003)	1	
12	GM00001268	SCREW 2.6X10KA(B0126100121)	6	
13	GM00001272	ROTATOR BRACKET R(C0120801004)	1	
14	GM00001279	SPRING LID (C1020801001)	1	
15	GM00001270	SPRING (B1214801020)	1	
16	GM00001274	RIGHT ROTATOR (C0120801006)	1	
17	GM00001265	MAGNET RING(A)(A2301005800)	1	
18	GM00001282	FIX PLATE (C3020801001)	1	
19	GM00001280	TURNING SHAFT (C1020801002)	1	
20	GM00001283	HOOK ASSY (G0180100101)	1	
21	GM00001269	SCREW 3X12PB(B0130120202)	4	
22	GM00001276	REAR CASE HEAD (C0120801008)	1	
23	GM00001278	HOOK LATCH COVER(C0120801010)	1	
24	GM00001277	HOOK HOLDER (C0120801009)	1	
25	GM00001267	SCREW 2.6X8PWB(B0126080006)	2	
26	GM00001284	LED CIRCUIT ASSY(G0180100102)	1	
27	GM00001281	LENS (C1020801003)	1	
28	GM00001267	SCREW 2.6X8PWB(B0126080006)	2	
29	GM00001275	FRONT CASE HEAD(C0120801007)	1	
	GM00001288	SHOULDER HOOK SET		