


RYOBI MULTI-TOOL - MODEL NUMBER MT100



Ref #	Part #	Description	Qty	Context Note	Foot Note
1	290011083	Power Cord Assembly	1	(Inc. Key No. 2)	
2	5629001	Bend Relief	1		
3	760223005	Switch	1		
4	201200003	Housing Assembly	1	(Inc. Key Nos. 17 and 19)	
5	550339001	Rubber Plug	3		
6	570301005	Rubber Pad	1		
7	340912001	Variable Speed Dial	1		
8	280110003	Circuit Board Assembly	1		
9	230322001	Motor Assembly	1		
10	303973001	Spline Shaft Assembly	1		
11	680582007	Needle Bearing	1		
12	303972001	Output Shaft Assembly	1		
13	692496002	Blade Adapter	1		
14	560324002	O-Ring	1		
15	692512002	Sleeve	1		
16	661379002	Screw (M6 x 18 mm)	1		
17	940488222	Data Label	1		
18	660203060	Screw (M3 x 12 mm)	12		
19	940114155	Logo Label	1		
20	681429002	Scraper Blade	1		
21	681458010	Wood/Metal Blade	1		
22	303590006	Sanding Pad	1		
23	902423001	Sanding Paper (60 Grit)	3		
24	902424001	Sanding Paper (120 Grit)	3		
25	6800201	Hex Key (M4)	1		
	988000686	Operator's Manual		Not Shown	