


RYOBI 18 VOLT JIG SAW - MODEL NUMBER P521



## RYOBI 18 VOLT JIG SAW – MODEL NUMBER P521

The model number will be found on a label attached to the motor housing. Always mention the model number in all correspondence regarding your **JIG SAW** or when ordering repair parts.

### PARTS LIST

KEY PART NO. NUMBER	DESCRIPTION	QTY.	KEY PART NO. NUMBER	DESCRIPTION	QTY.		
1	660302002	Screw (10-24 x 1/2 in.).....	2	31	671112001	Sleeve.....	1
2	630847003	Clamp Plate .....	1	32	300477004	Bearing Block Assembly w/Bearing.....	1
3	550432001	Rubber Tube .....	1	33	660212001	Screw (M4 x 6 mm).....	2
4	631737001	Base.....	1	34	6703001	Spring Washer .....	2
5	660302001	Screw (10-24 x 3/8 in.).....	1	35	630193002	Mounting Plate .....	1
6	550424002	Detent Button .....	1	36	610377002	Pinion.....	1
7	680909001	Spring .....	1	37	740527001	Motor .....	1
8	514042001	Orbital Knob .....	1	38	570263001	Rubber Cushion.....	1
9	680910004	Rod .....	1	39	570264001	Rubber Cushion.....	1
10	200202473	Housing Assembly.....	1	40	270001122	Switch Assembly .....	1
11	514047001	Blade Door.....	1	41	6620805	Screw (M4 x 16 mm).....	11
12	660439002	Screw (M4 x 8 mm).....	2	42	660203004	Screw (M3 x 16 mm).....	1
13	680906003	Pin.....	1	43	300306017	Heat Sink Assembly .....	1
14	300577025	Blade Guide Assembly .....	1	44	514045001	Safety Button.....	1
15	630848002	Strip Nut .....	1	45	670998004	Spring .....	1
16	660944001	Laser Adjust Nut.....	1	46	940230135	Laser Warning Label (Spanish).....	1
17	671363001	Spring For Adjust Laser.....	2	47	680907001	Hex Key (1/8 in.) .....	1
18	660126001	Nut (M4 x 2.3 Mm, Square) .....	1	48	681070001	Hex Key (5/64 in.) .....	1
19	570653002	Rubber Cover .....	1	49	690227036	Cut-Metal Blade .....	1
20	760270004	Switch (For Laser Control).....	1	50	690227035	Cut-Wood Blade.....	1
21	300549056	Laser Assembly .....	1	51	200292003	Plug In Lanyard.....	1
22	513433001	Laser Holder .....	1	52	940054127	Logo Label.....	1
23	681046002	Metal Wire (Blade Guard).....	1	53	940055122	Data Label .....	1
24	630849001	Return Spring .....	1	54	940214110	Laser Data Label.....	1
25	630845003	Slide Guide Plate .....	1	55	940230134	Laser Warning Label (English) .....	1
26	301007004	Quick Clamp Blade Assembly .....	1	56	940230133	Laser Warning Label (French).....	1
27	300019002	Bushing Assembly w/Bearing.....	1	983000935	Operator's Manual (960001247)		
28	220016102	Gear Assembly .....	1		6-7-12		
29	630843002	Drive Plate .....	1		(REV:01)		
30	630844001	Washer.....	1				