

Radio Box - 3 601 D29 710 - PB 360 S

www.powertools-aftersaleservice.com



BOSCH

Item	Part Number	Description	Illustration	Price	Quantity	Price Group
1	2 610 008 308	Aluminum Tubing	2	-,-	4	18
2	2 610 008 309	Aluminum Tubing	2	-,-	2	16
3	2 610 008 310	Aluminum Tubing	2	-,-	4	19
4	2 610 008 311	Aluminum Tubing	2	-,-	2	18
5	2 610 008 312	Protective Grille	1	-,-	1	20
6	2 610 008 313	Cover Flap	1	-,-	1	23
7	2 610 008 314	Cover Flap	1	-,-	1	22
10	2 610 008 315	Fuse Holder	1	-,-	1	15
11	2 610 008 316	Radio Antenna	1	-,-	1	21
12	2 610 008 317	Damping rubber	2	-,-	4	23
13	2 610 008 321	Rubber Plug	1	-,-	1	12
14	2 610 008 322	Rubber Plug	1	-,-	1	10
15	2 610 008 323	Rubber Plug	1	-,-	1	10
16	2 610 008 324	Rubber Plug	1	-,-	1	10
17	2 610 008 325	Door Seal	1	-,-	1	-
18	2 610 008 326	Door Seal	1	-,-	1	-
19	2 610 008 327	Rotary Knob	1	-,-	1	12
21	2 610 008 328	Rotary Knob	1	-,-	1	12
22	2 610 008 329	Cover Flap	1	-,-	1	11
23	2 610 008 330	Holder	1	-,-	1	10
24	2 610 008 331	Corner Protection	2	-,-	2	14
25	2 610 008 332	Corner Protection	2	-,-	2	14
26	2 610 008 333	Corner Protection	2	-,-	2	14
27	2 610 008 334	Corner Protection	2	-,-	2	14
28	2 610 008 335	Corner Protection	2	-,-	2	17
29	2 610 008 336	Corner Protection	2	-,-	2	17
30	2 610 008 337	Corner Protection	2	-,-	2	17
31	2 610 008 338	Corner Protection	2	-,-	2	17
32	2 610 008 339	Cable Holder	1	-,-	4	11
33	2 610 012 187	Holding Handle	1	-,-	1	23
34	2 610 008 353	Housing Base	1	-,-	1	-
35	2 610 008 361	Damping rubber	2	-,-	2	16
36	2 610 008 362	Damping rubber	2	-,-	1	17

Item	Part Number	Description	Illustration	Price	Quantity	Price Group
37	2 610 008 363	Damping rubber	2	-,-	1	17
42	2 610 008 343	Av-Cable	1	-,-	1	16

Illustration - Type E





Illustration - Type E



Information subject to change without further notice.