

Parts List for PCC792LA Type 1

Item Number	Part Number	Description	Qty Required
1	90626024	HOUSING SET	1
2	90616825	FRAME	1
3	90616826	FRAME COVER	1
4	90624433	END CAP	1
5	90621610	RUBBER PLUG	3
6	90615767	TRIGGER	1
7	098185-20	PIN	1
8	90551259	SPRING	1
9	90620174	LOCK OFF	1
10	90623653	LEVER	1
11	90629863	PIVOT	1
12	90624129	TORSION SPRING	1
13	90633248	PTO ASSEMBLY	1
15	90633321	ROLLER	1
16	N082403	DOWEL PIN	1
17	90629538	BUMPER	1
18	638469-00	BUMPER	1
19	90617917	SPRING	1
20	90633249	DEPTH GUIDE	1
21	90616223	HOUSING	1
22	90616224	HOUSING	1
23	90626617	PCB ASSEMBLY	1
24	90624621	END BRIDGE	1
25	90624714	ARMATURE & BRG	1
26	90623216	MAGNET RING	1
27	90616323	FLYWHEEL	1
28	90618959	TAPE	1

Parts List for PCC792LA Type 1

Item Number	Part Number	Description	Qty Required
29	90559833	BALL BEARING	1
30	90615722	RETAINING RING	1
31	90622035	BEARING PLATE	1
32	330041-61	ROLLER PIN	1
33	N403227	DETENT PIN	1
34	588470-00	PIN	1
35	90610773	NUT	1
36	90516498	SPRING	2
37	330019-04	SCREW,PLASTITE	11
38	90617387	MAGAZINE ASSEMBLY	1
39	330019-05	SCREW,PLASTITE	2
40	330045-05	LOCK SCREW	7
41	90621828	WASHER	2
42	330045-07	SCREW M4X20 T20	8
43	330019-38	SCREW	4
44	608175-00	SCREW	2
45	582193-00	SCREW	1
46	90626342	MACHINE SCREW	1
61	90624386	BRUSH BOX	2
62	90624385	BRUSH ASSEMBLY	1
63	90624388	BRUSH ASSEMBLY	1
64	90621006	MOUNT	1
65	90631918	HEAT SHRINK SLEEVE	2
66	90624199	HOLDER	1
67	90626619	PCB ASSEMBLY	1
99	330019-41	SCREW	1
100	90626069	BELT HOOK	1

Parts List for PCC792LA Type 1

Item Number	Part Number	Description	Qty Required
118	90625100	WARNING LABEL	1
119	90625098	RATING LABEL	1
120	90617821	NOMAR PAD	2
141	90633254	DRIVER ASSEMBLY	1
142	90629537	RETURN DEVICE	1
150	90621734	INFORMATION LABEL	1
866	PCC680L	BATTERY PACK	1
871	PCC692L	CHARGER	1