



Parts List for PCE380K Type 1

Item Number	Part Number	Description	Qty Required
1	5140188-22	SCREW	7
2	5140188-23	SPINDLE LOCK BUTTON	1
3	5140188-24	SPRING	1
4	5140188-25	DUST CAP	1
5	5140188-26	DUST CAP	2
6	5140188-27	LOCK WASHER	1
7	5140188-28	CIRCLIP	2
8	5140188-29	BALL BEARING	4
9	5140188-30	CIRCLIP	1
10	5140188-31	CIRCLIP	1
11	5140188-32	BALL BEARING	1
12	5140188-33	CIRCLIP	2
13	5140188-34	PINION	1
14	5140188-35	STEEL BALL	1
15	5140188-36	BALL BEARING	1
16	5140188-37	SELF TAPPING SCREW	6
17	5140188-38	SPINDLE	1
18	5140188-39	DUST PIPE ASSY.	1
19	5140188-40	DUST WASHER	1
20	5140188-41	CIRCLIP	1
21	5140188-42	BLADE	1
22	5140188-43	OUTER FLANGE	1
23	5140188-44	BLADE SCREW	1
24	5140188-45	DUST WASHER	1
25	5140188-46	BAFFLE	1
26	5140188-47	LOCKWASHER	1
27	5140188-48	BALL BEARING	1

Parts List for PCE380K Type 1

Item Number	Part Number	Description	Qty Required
28	5140188-49	SCREW	1
29	5140188-50	CONNECTING ROD	1
30	5140188-51	BALL BEARING	2
31	5140188-52	CIRCLIP	1
32	5140188-53	O-RING	1
33	5140188-54	ADAPTOR SLEEVE	1
34	5140188-57	CARBON BRUSH	2
35	5140188-58	BRUSH HOLDER	1
36	5140188-59	SELF TAPPING SCREW	2
37	5140188-60	BALL BEARING	1
38	5140188-61	SLEEVE BEARING	1
39	5140188-62	BRUSH HOLDER	1
40	5140188-63	CORD CLAMP	1
41	5140188-64	POWER CORD	1
42	5140188-65	TERMINAL BLOCK	2
43	5140188-66	STRAIN RELIEF	1
44	5140188-67	TERMINAL	2
45	5140188-68	LEFT HOUSING	1
46	5140188-69	SWITCH	1
47	5140188-70	KNOB	1
48	5140188-71	SPRING	2
49	5140188-72	TRIGGER	1
50	5140188-73	SCREW	1
51	5140188-74	STOP PIN	1
52	5140188-75	LINKAGE	1
53	5140188-76	CONNECTOR	1
54	5140188-77	LOCK NUT	3

Parts List for PCE380K Type 1

Item Number	Part Number	Description	Qty Required
55	5140188-78	WASHER	1
56	5140188-79	CLAMP	1
57	5140188-80	SELF TAPPING SCREW	2
58	5140188-81	SCREW	1
59	5140188-82	TORSION SPRING	1
60	5140188-83	SCREW	1
61	5140188-84	SPRING	1
62	5140188-85	COVER	1
63	5140188-86	SCREW	1
64	5140188-87	EDGE GUIDE	1
65	5140188-88	SPRING	1
66	5140188-89	KNOB	1
67	000000-00	No Longer Available	9
68	5140188-90	LABEL	1
69	5140188-91	RIGHT HOUSING	1
70	5140188-92	HEX KEY	1
71	5140188-93	SCREW	3
72	5140188-94	LASER SEAT	1
73	5140188-95	BATTERY	2
74	5140188-96	SELF TAPPING SCREW	2
75	5140188-97	HOUSING COVER	1
76	5140188-98	SELF TAPPING SCREW	1
801	5140194-53	GEARBOX ASSY	1
802	5140194-54	GEAR ASSEMBLY	1
803	5140194-55	GEAR ASSEMBLY	1
804	5140194-56	GUARD ASSEMBLY	1
805	5140188-55	FIELD	1

Parts List for PCE380K Type 1

Item Number	Part Number	Description	Qty Required
806	5140188-56	ARMATURE	1
807	5140194-57	DEPTH ADJ ASSY	1
808	5140194-58	GUARD ASSY.	1
809	5140194-59	SHOE ASSEMBLY	1
810	5140194-60	LASER ASSEMBLY	1